

# Kodak EasyShare CX4310 digital camera



## User's Guide

Visit Kodak on the World Wide Web at [www.kodak.com](http://www.kodak.com)




Eastman Kodak Company  
343 State Street  
Rochester, New York 14650

© Eastman Kodak Company, 2003

Kodak and EasyShare are trademarks of Eastman Kodak Company.  
All screen images are simulated.


P/N 6B8606

## Camera Front




- |                    |                    |
|--------------------|--------------------|
| 1 Shutter button   | 5 Viewfinder lens  |
| 2 Flash unit       | 6 Lens             |
| 3 On / Off switch  | 7a USB connector   |
| 4 Self Timer light | 7b DC in connector |

## Camera Bottom



- |  |                       |
|--|-----------------------|
| 1 Camera Dock connector<br>(door shown closed) | 2 Tripod mount socket |
|  | 3 Battery door        |

## Camera Back



- |                                   |                    |
|-----------------------------------|--------------------|
| 1 Viewfinder                      | 8 SD/MMC card door |
| 2 Ready light                     | 9 Flash button     |
| 3 LCD (Liquid Crystal Display)    | 10 Share button    |
| 4 Shutter button                  | 11 Delete button   |
| 5 4-way arrow / Zoom / OK buttons | 12 Review button   |
| 6 Wrist strap post                | 13 Menu button     |
| 7 Video out port                  |                    |



# Table of Contents

|   |  |    |
|---|--|----|
| 1 | Getting Started .....                              | 1  |
|   | Install the Software First .....                   | 1  |
|   | Need This Guide in Large Print? .....              | 1  |
|   | Camera Package Contents .....                      | 2  |
|   | Attaching the Wrist Strap .....                    | 3  |
|   | Attaching the Lens Cap .....                       | 3  |
|   | Loading the Batteries .....                        | 4  |
|   | Turning the Camera On and Off .....                | 5  |
|   | Using the 4-Way Arrow/Zoom/OK Button .....         | 5  |
|   | Selecting a Language .....                         | 6  |
|   | Setting the Clock .....                            | 7  |
|   | Checking Camera Status .....                       | 8  |
|   | Inserting an SD/MMC Card .....                     | 9  |
|   | Choosing Internal Memory or SD/MMC Card .....      | 10 |
|   | Camera Modes .....                                 | 11 |
|   | Important Battery Information .....                | 12 |
| 2 | Taking Pictures—Capture Mode .....                 | 15 |
|   | Take a Picture Anytime .....                       | 15 |
|   | Taking a Picture .....                             | 15 |
|   | Liveview—Using the LCD to Frame Your Subject ..... | 16 |
|   | Quickview—Reviewing the Picture Just Taken .....   | 17 |

|   |           |
|---|-----------|
| Using the Flash.....                          | 18        |
| Using Digital Zoom.....                       | 19        |
| Changing Picture-Taking Options.....          | 20        |
| <b>3 Reviewing Pictures—Review Mode .....</b> | <b>27</b> |
| To Enter Review Mode.....                     | 27        |
| To Access the Review Menus .....              | 28        |
| Viewing Single Pictures.....                  | 29        |
| Viewing Multiple Pictures.....                | 29        |
| Deleting Pictures .....                       | 30        |
| Magnifying Pictures .....                     | 30        |
| Protecting Pictures From Deletion .....       | 31        |
| Running a Slide Show.....                     | 31        |
| Displaying Pictures on a Television.....      | 33        |
| Copying Pictures .....                        | 34        |
| Viewing Picture Information .....             | 35        |
| <b>4 Tagging Pictures—Share Mode .....</b>    | <b>37</b> |
| When Can I Tag My Pictures? .....             | 37        |
| To Access Share Mode/Menus.....               | 37        |
| Tagging Pictures for Printing .....           | 38        |
| Tagging Pictures for Emailing .....           | 39        |
| Tagging Pictures as Favorites.....            | 40        |

|   |   |    |
|---|---|----|
| 5 | Customizing Camera Settings—Setup Mode .....    | 41 |
|   | To Access Setup Mode/Menus .....                | 41 |
|   | Returning to the Previous Menu .....            | 42 |
|   | Changing the Print Quantity Default .....       | 42 |
|   | Turning Off Quickview .....                     | 43 |
|   | Turning On Liveview .....                       | 43 |
|   | Setting Video Out .....                         | 44 |
|   | Formatting Memory or MMC/SD Card .....          | 45 |
|   | Viewing Camera Information .....                | 46 |
| 6 | Installing the Software .....                   | 47 |
|   | System Requirements .....                       | 47 |
|   | Install the Software .....                      | 49 |
| 7 | Connecting to the Computer .....                | 51 |
|   | Important—Before You Connect .....              | 51 |
|   | Connecting to the Computer .....                | 51 |
|   | Transferring Pictures to Your Computer .....    | 52 |
|   | Printing Pictures from Your Computer .....      | 52 |
|   | Printing from an SD/MMC Card .....              | 52 |
|   | Print With or Without a Computer .....          | 52 |
| 8 | Using the Optional Camera Dock II .....         | 53 |
|   | Camera Dock Package Contents .....              | 53 |
|   | Installing the Camera Insert .....              | 54 |
|   | Connecting the Camera Dock .....                | 55 |
|   | Installing the Battery Pack in the Camera ..... | 56 |

|   |    |
|---|----|
| Docking the Camera .....                  | 57 |
| Charging the Battery Pack .....           | 58 |
| Transferring Pictures .....               | 59 |
| Caution When Using a Tripod.....          | 59 |
| Earlier Camera Dock Model.....            | 60 |
| <br>                                      |    |
| 9 Troubleshooting .....                   | 61 |
| Troubleshooting—Camera .....              | 61 |
| Troubleshooting—Camera Dock II .....      | 74 |
| <br>                                      |    |
| 10 Getting Help .....                     | 77 |
| Helpful Web Links.....                    | 77 |
| Help in this User Guide .....             | 78 |
| Software Help .....                       | 78 |
| Telephone Customer Support.....           | 78 |
| <br>                                      |    |
| 11 Appendix .....                         | 81 |
| Camera Specifications.....                | 81 |
| Original Factory Settings—Camera.....     | 83 |
| Upgrading Your Software and Firmware..... | 83 |
| Tips, Safety, Maintenance .....           | 84 |
| Picture Storage Capacities.....           | 85 |
| Locating Pictures on an MMC/SD Card.....  | 85 |
| Card File Naming Conventions .....        | 86 |
| Battery-Saving Features.....              | 87 |
| Optional AC Adapter .....                 | 87 |
| Camera Dock II Specifications .....       | 88 |
| FCC Compliance and Advisory.....          | 89 |

# 1 Getting Started

## Install the Software First

You must install the Kodak EasyShare software on your computer before you connect the camera to the computer or attempt to transfer pictures.

See [Chapter 6, Installing the Software](#), or the Quick Start Guide for directions.

## Need This Guide in Large Print?

For a large print version of this User's Guide:


- 1 Go to <http://www.kodak.com/go/cx4310support>.
- 2 Navigate to the Manuals section.
- 3 Click *View as PDF* to open the User's Guide.
- 4 On a Windows OS-based computer or Mac OS 8.6 or 9.x:
  - From the File menu, select Print.
  - In the Print window, select Fit to Page.

On Mac OS X:

- From the File menu, select Page Setup.
  - Change Scale to 200%.
- 5 Print as usual.

## Camera Package Contents

Contents subject to change. Check box for contents listing.




- |                         |   |
|-------------------------|---|
| 1 Camera                | 5 USB cable   |
| 2 Wrist strap           | 6 Video cable (for viewing<br>pictures on television) |
| 3 Lens cap              |   |
| 4 Custom camera insert* |   |

Also included but not shown: 2 Kodak digital camera batteries; User's Guide or User's Guide CD; Quick Start Guide; and Kodak EasyShare software CD.

**NOTE:** \*The custom camera insert fits your camera to the optional Kodak EasyShare camera dock, camera dock II, or EasyShare printer dock 4000. **DO NOT DISCARD.**


See [page 53](#) for details about purchasing and using a camera dock.

## Attaching the Wrist Strap




- 1 Thread the short loop of the strap through the wrist strap post.
- 2 Thread the long end of the strap through the short loop. Pull until secure.

## Attaching the Lens Cap



- 1 Thread the lens cap string through the loop in the wrist strap as shown.




- 2 Put the lens cap on the lens. Depress the tabs on the lens cap, fit the cap on the lens, and release the tabs.


To protect the lens, put the lens cap on whenever you are not taking pictures.

## Loading the Batteries


Kodak digital camera batteries (2, AA) are included with your camera.



AA



CRV3  
(optional)



- 1 Turn **off** the camera.
- 2 On the bottom of the camera, slide the battery door and lift to open.
- 3 Insert the AA batteries as shown.
- 4 Close the battery door.

### **IMPORTANT BATTERY INFORMATION**


**For acceptable battery life and to make sure your camera operates dependably, do not use alkaline batteries.**

If you purchased an optional Kodak CRV3 lithium battery, insert it as shown.

If you purchased a Kodak EasyShare camera dock II, see [page 56](#) for details on using the Kodak EasyShare Ni-MH rechargeable battery pack.


See [page 12](#) for the types of batteries you can use in your camera.

## Turning the Camera On and Off



- 1 Slide the On/Off switch to the On position.  
*The ready light blinks green while the camera performs a self-check, then glows steady green when the camera is ready to take pictures.*
- 2 To turn off the camera, slide the On/Off switch to the Off position.  
*The camera completes operations that are in process.*

## Using the 4-Way Arrow/Zoom/OK Button



**View pictures**—press ▲/▼ to scroll through your pictures. Press ▼ to display multiple thumbnails. See [page 29](#).

**Zoom**—press ▲/▼ to zoom in or out when taking pictures. See [page 19](#).

**Check status**—press ▼ to display the status bar. See [page 8](#).

**Navigate menus**—press ▲/▼ and ▲/▼ to scroll through the menus and fields.

**Select**—press OK to make a selection.

**Magnify**—press OK to magnify a picture in Review mode. See [page 30](#).

## Selecting a Language

You can display menus and screen messages in different languages.

The Language screen is automatically displayed the first time you turn on the camera. If this is the first time the camera has been turned on, go to step 4.

To change the language after that:

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.




- 3 Highlight Language , then press the OK button.
- 4 Press  to highlight a language, then press the OK button.
- 5 Press the Menu button to turn off the menu.

*Text is displayed in the selected language.  
This setting remains until you change it.*

## Setting the Clock

The Date & Time screen appears the first time you turn on the camera or if the battery is removed for an extended time. If this is the first time the camera has been turned on, go to step 4.

To set the date and time after that:



- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup  , then press the OK button.
- 3 Highlight Date & Time  , then press the OK button.

*The date format is YYYY/MM/DD in a 24-hour format.*


- 4 Press  to move through the fields.  
Press  to adjust the settings.
- 5 Press the OK button to accept the changes.
- 6 Press the Menu button to turn off the menu.

*The setting remains until you change it.*

NOTE: Depending on your computer operating system, Kodak EasyShare software may allow your computer to automatically update the camera clock when you connect the camera. See the Kodak EasyShare software Help for details.

## Checking Camera Status

To check the current camera settings, press the down arrow in Capture mode or the flash button any time:



### Camera Status Icons

|                                 |            |                  |  |
|---------------------------------|------------|------------------|--|
|                                 | Date stamp | 072              | Pictures remaining                               |
|                                 | Close up   | Internal<br>Card | Storage location                                 |
| Auto<br>Off<br>Fill<br>Red-eye  | Flash mode | <br><br>Share    | Camera mode<br>(icons not displayed in Liveview) |
| Best ★★★<br>Better ★★<br>Good ★ | Quality    |                  | Low Battery                                      |
|                                 | Self Timer |                  | Exhausted battery<br>(blinking)*                 |

### Battery Status

If no battery icon appears on the LCD, the battery is fully charged.

\*A blinking battery icon means the battery is too weak to power the camera. The ready light blinks red for five seconds, then the camera turns off.

## Inserting an SD/MMC Card


Optional SD/MMC cards provide removable, reusable storage for pictures.



### CAUTION:

The card can only be inserted one way; forcing it may damage the camera or card.

Do not insert or remove a card when the green ready light is blinking; it may damage your pictures, card, or camera.



- 1 Turn off the camera.
- 2 Open the card door.
- 3 Orient the card as shown.
- 4 Push the card into the slot to seat the connector. (To remove the card, push it in, then release it. When the card is partially ejected, pull it out.)
- 5 Close the door.

See [page 85](#) for storage capacities. Purchase SD/MMC cards at a dealer of Kodak products or on our Web site at <http://www.kodak.com/go/cx4310accessories>.

## Choosing Internal Memory or SD/MMC Card

The camera offers two options for storing pictures:

**Internal Memory**—store up to 14 pictures (at Best quality) in the 16 MB internal memory.

**SD/MMC Card**—store as many pictures as you like, depending on the size of the card.

See [page 85](#) for storage capacities. Purchase SD/MMC cards at a dealer of Kodak products or on our Web site at <http://www.kodak.com/go/cx4310accessories>.

### Changing Your Storage Location Setting

Use the Image Storage menu, available in Capture and Review modes, to change the setting.

- 1 Turn on the camera.
- 2 Press the Menu button.
- 3 Select Image Storage , then press the OK button.  

- 4 Press  $\Delta/\nabla$  to highlight an option, then press the OK button:
  - Auto (default)**—the camera uses the card if one is in the camera ; the camera uses internal memory if no card is in the camera .
  - Internal Memory**—the camera always uses internal memory, even if a card is installed .
- 5 Highlight Continue, then press the OK button again.  
*The camera changes storage locations. The setting remains until you change it and applies to all camera functions (Capture, Review).*
- 6 Press the Menu button to turn off the menu.

## Camera Modes

The camera has four modes: Capture, Review, Share, and Setup. You can always tell which mode the camera is in:



Capture

**Capture** —the LCD is blank, no image is displayed. Press the down arrow to display the status bar and mode icon. Press OK to enter Liveview. See [Chapter 2, Taking Pictures—Capture Mode](#). But remember, you can press the Shutter button and take a picture anytime, no matter what mode the camera is in!



Review

**Review** —a picture is displayed; the mode icon is displayed on the LCD. See [Chapter 3, Reviewing Pictures—Review Mode](#).



Share

**Share**—Print, Email, and Favorites appear in the menu bar; a picture is displayed. See [Chapter 4, Tagging Pictures—Share Mode](#).



Setup

**Setup**—Setup mode is an option on both the Capture and Review menus. The menu bar is bright yellow; a picture is never displayed. See [Chapter 5, Customizing Camera Settings—Setup Mode](#).

## Important Battery Information

Choose the replacement battery that fits your needs—and get the best performance.

### Battery Replacement Types/Battery Life

Your camera can use the following types of Kodak batteries. Actual battery life may vary based on usage.


CRV3 lithium battery

AA (2) lithium batteries

Ni-MH rechargeable battery pack\* (per charge)

AA (2) Ni-MH rechargeable batteries (per charge)

Kodak digital camera batteries, AA (2) (included with camera)



\* Included with the Kodak EasyShare camera dock, camera dock II, and printer dock 4000

**We do not recommend or support alkaline batteries.** For acceptable battery life, and to make sure your camera operates dependably, use the replacement batteries listed above.

For information on batteries, visit <http://www.kodak.com/global/en/service/batteries/batteryUsage.jhtml>

## Extending Battery Life

- Battery life depends significantly on battery age, usage conditions, and type. Digital cameras are demanding on batteries. Not all batteries perform well under these challenging conditions.
- Limit the following activities that quickly deplete battery power:
  - Reviewing your pictures on the camera screen (see [page 27](#))
  - Using Liveview (see [page 16](#))
  - Using Quickview (see [page 17](#)).
  - Excessive use of the flash
- Purchase an optional Kodak 3-volt AC adapter to power your camera (see [page 87](#)).
- Purchase an optional Kodak EasyShare camera dock (see [page 53](#)). The camera dock powers your camera, transfers pictures, and is also a battery charger for its included Kodak EasyShare Ni-MH rechargeable battery pack.
- Purchase an optional Kodak EasyShare printer dock 4000 (see [page 52](#)). The printer dock 4000 powers your camera, makes 4 x 6 prints with or without a computer, transfers pictures, and is also a battery charger for its included Kodak EasyShare Ni-MH rechargeable battery pack.
- Dirt on the battery contacts can affect battery life. Wipe the contacts with a clean, dry cloth before loading batteries in the camera.
- Battery performance is reduced at temperatures below 41° F (5° C). Carry spare batteries when using your camera in cold weather, and keep them warm. Do not discard cold batteries that do not work; when they return to room temperature, they may be usable.

## Battery Safety and Handling

- Do not allow batteries to touch metal objects, including coins. Otherwise, a battery may short circuit, discharge energy, become hot, or leak.
- For rechargeable battery disposal information, visit the Rechargeable Battery Recycling Corporation Web site at [www.rbrc.com](http://www.rbrc.com).




## 2 Taking Pictures—Capture Mode

### Take a Picture Anytime

The camera is in Capture mode  when you turn it on. Press the Shutter button to take a picture. But remember, you can press the Shutter button and take a picture anytime, no matter what mode the camera is in!

### Taking a Picture

Before you take a picture, make sure your picture storage location is set the way you want it (see [page 10](#)).



- 1 Use the Viewfinder to frame your subject. (Or press the OK button to turn on Liveview. See [page 16](#).)
- 2 Press the Shutter button half-way down to set the exposure and focus.
- 3 Press the Shutter button completely down to take the picture.

*The ready light blinks green while the picture is saved. The ready light blinks orange if the flash is recharging or if there is an auto-exposure error.*



#### CAUTION:

**Do not insert or remove a card when the green ready light is blinking. It may damage your pictures, card, or camera.**

## Liveview—Using the LCD to Frame Your Subject

When you turn on Liveview, the LCD displays a live image of what the lens sees. Look at the LCD to frame your picture.



- 1 Make sure the camera is in Capture mode (  on the LCD).
- 2 Press the OK button to turn on Liveview.
- 3 Frame your picture in the LCD.
- 4 Take the picture.
- 5 To turn off Liveview, press the OK button.

NOTE: Liveview quickly depletes battery power; use it sparingly. To conserve battery power, Liveview automatically turns off after one minute.

To change the Liveview setting so it is on whenever the camera is on, see [page 43](#).

## Quickview—Reviewing the Picture Just Taken

After you take a picture, the LCD displays a Quickview of that picture for 5 seconds. While the picture is displayed, you can:




- **Review It.** If you take no action, the picture is saved.
- **Delete it.** Press the Delete button while the picture and are displayed.

NOTE: To save battery power, you can turn off the Quickview feature. See [page 43](#).

## Using the Flash

Use the flash when you take pictures outdoors in heavy shadows, at night, or indoors. Flash is effective at the distances of 1.6 to 9.8 feet (0.5 to 3 m).



Press the **⚡** button repeatedly to scroll through the flash options.

The flash icon displayed on the LCD is the active option.

Current camera status icons are also displayed (see [page 8](#)). The LCD screen turns off after 3 seconds.



**Auto Flash**—flash fires when the lighting conditions require it. When the picture is taken, the camera flashes twice, once to set the exposure and once to take the picture.



**Flash Off**—flash never fires.



**Fill Flash**—flash fires every time you take a picture, regardless of the lighting conditions. When the picture is taken, the camera flashes twice, once to set the exposure and once to take the picture.



**Red-eye**—flash fires three times, once to set the exposure, once to reduce red-eye, and once to take the picture. The Red-eye option remains in effect until you change it. See [page 21](#) for an exception with Close-up.

**NOTE:** All flash options (except Red-eye) revert to Auto when the camera is turned off.

The camera uses slow shutter speeds in low-light conditions with the flash turned off. Take care to avoid camera shake; use a tripod or place the camera on a steady surface.

## Using Digital Zoom

Use Digital Zoom to zoom in two times closer to your subject. The lens does not move during Digital Zoom.

**IMPORTANT:** *You may notice a decrease in printed image quality when using Digital Zoom.*



- 1 Press the OK button to turn on Liveview.
- 2 Press ► to activate the digital zoom.  
*The LCD displays the zoomed image and the digital zoom icon ☒.*
- 3 Use the LCD to frame your subject, then take the picture. You must use Liveview to take the picture because the zoomed image is only displayed through the LCD and not the viewfinder.

**NOTE:** Digital zoom is turned off when you press the OK button, turn off the camera, turn Close-up on or off, or when the camera enters Auto power-off.

## Changing Picture-Taking Options

Use the Capture menus to change picture-taking options. If you are in Review, Share, or Setup modes you must return to Capture mode before you can access the Capture menus.

### To Return to Capture From Another Mode

To return to Capture from:

- Any mode, press the Shutter button to take a picture and revert to Capture.
- Review mode, press the Review button.
- Share mode, press the Share button.
- Setup mode, and you got there from Capture, press the Menu button.
- Setup mode, and you got there from Review mode, press the Menu button.

### To Access the Capture Menu


- 1 In Capture mode (LCD is blank, no picture is displayed), press the Menu button.
- 2 Press the Menu button to turn off the menu.

#### Capture Menus

|  |                           |  |                           |
|--|---------------------------|--|---------------------------|
|  Close-up               | <a href="#">(page 21)</a> |  Quality            | <a href="#">(page 24)</a> |
|  Self Timer             | <a href="#">(page 22)</a> |  Date Stamp         | <a href="#">(page 25)</a> |
|  Image Storage          | <a href="#">(page 10)</a> |  Orientation Sensor | <a href="#">(page 26)</a> |
|  Exposure Compensation | <a href="#">(page 23)</a> |  Setup             | <a href="#">(page 41)</a> |

## Taking Close-up Pictures

The Close-up setting helps you gain sharpness and detail at close range. The Close-Up focus distance is 5.9 to 19.7 in. (150 to 500 mm).



To turn on Close-up:

- 1 In Capture mode, press the Menu button.
- 2 Highlight Close-up , then press the OK button.
- 3 Highlight On, then press the OK button.
- 4 Press the Menu button to turn off the menu screen.

*The Close-up icon  appears in the status bar and the LCD automatically enters Liveview.*


- 5 Use the LCD to frame your subject and take the picture as usual.

*The Close-up setting turns off when you turn off the camera.*

NOTE: If the flash is set to Red-eye when you turn on Close-up, the flash setting changes to Auto; the flash then changes back to Red-eye when you turn off Close-up.

## Putting Yourself in the Picture

The Self Timer creates a 10-second delay between the time you press the Shutter button and the time the picture is taken.



- 1 In Capture mode, press the Menu button.
- 2 Highlight Self Timer , then press the OK button.
- 3 Highlight On, then press the OK button.
- 4 Press the Menu button to turn off the menu screen.
- 5 Place the camera on a flat surface or use a tripod.
- 6 Press the Shutter button.  
*The red Self Timer light turns on for 8 seconds, then blinks for 2 seconds. The picture is taken.*  
*The Self Timer turns off after you take the picture.*

## Setting Exposure Compensation

Use Exposure Compensation to control how much light is allowed into the camera. The exposure range is +2 to -2 in 1/2-step increments.

NOTE: This setting is ideal for controlling pictures in which the light source is behind the subject (backlit), or for correcting pictures that are too light or too dark.

- 1 In Capture mode, press the Menu button.

- 2 Highlight Exposure Compensation , then press the OK button.



- 3 Press  $\Delta/\nabla$  to select the Exposure Compensation setting.
  - If your pictures are too light, press  $\nabla$  to decrease (-) the value.
  - If your pictures are too dark, press  $\Delta$  to increase (+) the value.
- 4 Press the OK button to accept the change and return to the menu screen.
- 5 Press Menu to exit the menu screen.

*This setting remains until you change it.*

## Setting Picture Quality

Use the Quality setting to select a picture resolution:

- 1 In Capture mode, press the Menu button.
- 2 Highlight Quality ★, then press the OK button.

*The active Quality setting appears in the top left corner.*



- 3 Highlight an option:

**Best ★★★**—(3.2 MP, low compression) for printing up to 11 x 14 in. (27.9 x 35.6 cm); produces highest picture resolution, more detail, and largest file sizes.

**★★★** *appears in the status bar.*

**Better ★★**—(3.2 MP, high compression) for printing up to 8 x 10 in. (20.3 x 25.4 cm); pictures are medium resolution with smaller file sizes.

**★★** *appears in the status bar.*

**Good ★**—(0.8 MP) for emailing or screen display; pictures are lowest resolution with smallest file sizes.

**★** *appears in the status bar.*

- 4 Press the OK button.
- 5 Press the Menu button to turn off the menu screen.

*This setting remains until you change it.*

## Placing the Date on Pictures

Use Date Stamp to imprint the date on your pictures.

- 1 Make sure the camera clock is set to the correct date ([page 7](#)).
- 2 In Capture mode, press the Menu button.
- 3 Highlight Date Stamp , then press the OK button.
- 4 Highlight an option:
  - Off
  - YYYY MM DD**
  - MM DD YY**
  - DD MM YYYY**
- 5 Press the OK button.
- 6 Press the Menu button to turn off the menu.



*The current date is printed in the bottom right corner of new pictures. This setting remains until you change it.*

### Setting the Orientation Sensor

If you rotate the camera to take a picture (for example, a portrait shot), the Orientation Sensor rotates the picture so it is displayed correct side up during Quickview and Review.

The Orientation Sensor is turned on as the default. You can turn it off so that pictures are displayed in their original orientation.

NOTE: When your subject is above or below you (such as pictures of an object in the sky, on the ground, or when pointing down at small objects on a table), turn off the Orientation Sensor so that pictures are not rotated unnecessarily.

- 1 In Capture mode, press the Menu button.
- 2 Highlight Orientation  , then press the OK button.
- 3 Highlight On or Off, then press the OK button.
- 4 Press the Menu button to turn off the menu.


*This setting remains until you change it.*

# 3 Reviewing Pictures—Review Mode

Use Review mode  to view and work with the pictures that are stored in internal memory or on a card.

NOTE: Reviewing pictures on the LCD quickly depletes battery power. An optional AC adapter is available (see [page 87](#)).

## To Enter Review Mode



- 1 Press the Review button.  
The last picture you took or reviewed is displayed. The Review icon  appears at the bottom of the LCD.
- 2 Press the Review button again to exit Review and return to Capture mode.  
The icons displayed with the picture indicate applied features.

## Picture Information Icons

|   |   |   |   |                |  |
|---|---|---|---|----------------|--|
|  |  |  2 |  | 072            | <br>Internal memory<br><br>Memory Card |
| Email   | Favorite  | Print tag, # of copies  | Protected   | Picture number | Picture Location   |

|  |   |   |
|--|---|---|
|  Review |  |  |
| Mode indicator   | Low battery   | Exhausted battery (blinking)  |

# To Access the Review Menus

Use the Review menus to work with the pictures that are stored in internal memory or on a card.

- 1 Press the Review button.
- 2 Press the Menu button.
- 3 Press the Menu button to turn off the menus.

## Review Menus

|  |  |   |  |
|--|--|---|--|
|  | <b>Magnify</b> ( <a href="#">page 30</a> )       |  | <b>Copy</b> ( <a href="#">page 34</a> )                |
|  | <b>Protect</b> ( <a href="#">page 31</a> )       |  | <b>Multi-up</b> ( <a href="#">page 29</a> )            |
|  | <b>Image Storage</b> ( <a href="#">page 10</a> ) |  | <b>Picture Information</b> ( <a href="#">page 35</a> ) |
|  | <b>Slide Show</b> ( <a href="#">page 31</a> )    |  | <b>Setup</b> ( <a href="#">page 41</a> )               |

## Viewing Single Pictures




- 1 Press the Review button.

*The camera displays the last picture that was taken or reviewed.*

- 2 Press  $\blacktriangleleft/\triangleright$  to scroll backward or forward through the pictures.

## Viewing Multiple Pictures



- 1 Press the Review button.

- 2 Press  $\blacktriangledown$ .

*Nine pictures (thumbnails) are displayed at once.*

- 3 Press  $\blacktriangleleft/\blacktriangledown$  to display the previous or next row of thumbnails.

- 4 Press  $\blacktriangleleft/\triangleright$  to scroll through the thumbnails one at a time.

*The selected picture is highlighted in yellow.*

- 5 Press the OK button to display a single view of the selected picture.

## Viewing Multiple Pictures—Review Menu

You can also view multiple pictures through the Review menu, Multi-up option.



- 1 Press the Review button, then press the Menu button.

- 2 Highlight Multi-up , then press the OK button.

*Nine pictures (thumbnails) are displayed at once.*

- 3 Navigate through the thumbnails as described above.

## Deleting Pictures



- 1 Press the Review button.
- 2 Select a picture in single view or highlight a picture in multiple view, then press the Delete button.
- 3 Highlight an option, then press the OK button:
  - PICTURE**—deletes the displayed picture.
  - EXIT**—exits the Delete screen.
  - ALL**—deletes all pictures from your current storage location.

NOTE: Protected pictures cannot be deleted; remove protection before deleting ([page 31](#)).


## Magnifying Pictures

- 1 Press the Review button, then press the OK button.  
*The picture is displayed at 2X magnification. The Magnify icon + and the magnification value are displayed on the screen.*
- 2 Press the OK button again to display the picture at 4X magnification.
- 3 Press  $\Delta/\nabla \leftarrow/\rightarrow$  to view different parts of the picture.
- 4 Press the OK button again to redisplay the picture at the original size.

NOTE: You can also magnify pictures through the Magnify menu: press the Review button, press the Menu button, highlight Magnify , then press the OK button.

## Protecting Pictures From Deletion

- 1 Press the Review button, then locate the picture to protect.
- 2 Press the Menu button.



- 3 Highlight Protect , then press the OK button.

*The Protect icon appears with the protected picture whenever it is displayed in the status bar. The picture cannot be deleted. (Formatting deletes even protected pictures, see [page 45](#)).*

- 4 To remove protection, press the OK button again.
- 5 Press the Menu button to turn off the menu.

## Running a Slide Show

Use the Slide Show to display your pictures on the LCD in the order in which you took them. To run a slide show on a television or other external device, see [page 33](#).

### Starting the Slide Show

- 1 Press the Review button, then press the Menu button.
- 2 Highlight Slide Show , then press the OK button.




- 3 Highlight Begin Show, then press the OK button.

*The pictures are each displayed once in the order in which you took them. Then the camera returns to the Menu screen. See [Turning On Loop, page 32](#), for continual display.*

- 4 To cancel the Slide Show, press the OK button.

## Changing the Display Interval

The default setting displays each picture for 5 seconds. You can increase the display interval up to up to 60 seconds.




- 1 On the Slide Show menu, highlight Interval, then press the OK button.
- 2 Press  $\Delta/\nabla$  to select a display interval. To scroll through the seconds quickly, press and hold  $\Delta/\nabla$ .
- 3 Press the OK button.

*The Interval setting remains until you change it.*

## Turning On Loop

When you turn on Loop, the slide show is continuously repeated.




- 1 On the Slide Show menu, press  $\nabla$  to scroll down to Loop; highlight Loop, then press the OK button.
- 2 Highlight On, then press the OK button.  
*The loop slide show begins immediately. It repeats continuously until you cancel it by pressing the OK button or until battery power is exhausted.*

*Loop reverts to Off when the loop slide show stops.*

## Displaying Pictures on a Television

You can run a slide show or display your pictures on a television, computer monitor, or digital projector (any device equipped with a video input).

NOTE: Ensure that the Video Out setting is correctly set to NTSC or PAL (see [page 44](#)).



- 1 Connect the video cable from the video out port on the camera to the video in port on the television. (Refer to your television User's Guide for details on video in setup.)  
*The camera LCD turns off; the television screen acts as the camera display.*
- 2 You can now use the television screen to review your pictures in single or multiple views, run a slide show, or do anything on the television screen that you can do on the camera LCD.

NOTE: If you connect or disconnect the video cable while a slide show is running, the slide show stops.

## Copying Pictures

You can copy pictures from a card to internal memory, or from internal memory to a card.

### Before you copy make sure that:

- A card is inserted in the camera.
- The camera's picture storage location is set to the location **from** which you are copying. See [Choosing Internal Memory or SD/MMC Card, page 10](#).

### Copy pictures:

- 1 Press the Review button, then press the Menu button.
- 2 Highlight Copy ►►, then press the OK button.



- 3 Highlight an option:

**PICTURE**—copies the current picture from your selected storage location to the other location.

**EXIT**—returns to the Copy screen.

**ALL**—copies all pictures from your selected storage location to the other location.

- 4 Press the OK button.

*A progress bar monitors the copy process.*

**NOTE: Pictures are copied, not moved.** To remove the pictures from the original location after they are copied, delete them (see [page 30](#)).

**Tags and protection are not copied.** Print, email, and Favorite tags are not copied with the picture (see [page 37](#) to re-apply tags). Protection settings are not copied (see [page 31](#) to re-apply protection).

## Viewing Picture Information



- 1 Press the Review button, then press the Menu button.
- 2 Highlight the Picture Info menu  , then press the OK button.

*The information about the displayed picture is view-only and includes: file name, location of the file if stored on a card (there are no directories in internal memory), date and time the picture was taken, and the quality setting.*
- 3 Press / to display the previous/next picture, with that picture's information.
- 4 To exit Picture Info, press the OK button.



# 4 Tagging Pictures—Share Mode

Press the Share button to tag your pictures as Favorites and for automatic printing and emailing. But remember, you can press the Shutter button and take a picture anytime, no matter what mode the camera is in!

NOTE: MAC OS 8.6 and 9.x do not support the Share button functions. OS X is recommended for full functionality.

## When Can I Tag My Pictures?

You can tag pictures whenever they are displayed on the LCD in Review mode (see [page 27](#)).

## To Access Share Mode/Menus

- 1 Press the Share button.
- 2 Press the Share button again to exit Share mode and return to Capture or Review mode.

### Share Menus



**Print** ([page 38](#))



**Email** ([page 39](#))



**Favorite** ([page 40](#))




**Print All** ([page 38](#))



**Cancel Prints** ([page 38](#))

## Tagging Pictures for Printing



- 1 Locate a picture, then press the Share button.
- 2 Highlight Print  and press the OK button.
- 3 Press  /  to select the number of copies (0-99). Zero removes the tag for that picture.  
*The Print icon  appears with the picture.*

*The default quantity is one. To change the default, see [page 42](#).*

- 4 To tag all pictures on the card or in internal memory, highlight Print All, press the OK button, then indicate the number of copies as described above.
- 5 To remove the print tagging for all pictures on the card or in internal memory, highlight Cancel Prints, then press the OK button.
- 6 Press the Share button to return to Capture mode.

### Printing Tagged Pictures

When you transfer the tagged pictures to your computer, the Kodak EasyShare software Print screen opens and lets you immediately print your pictures. See Kodak EasyShare software Help for details on printing.

## Tagging Pictures for Emailing

First, use Kodak EasyShare software to create an email address book on your computer, then copy up to 32 email addresses to the camera's internal memory. See Kodak EasyShare software Help for details.



- 1 Locate a picture, then press the Share button.
- 2 Highlight Email , then press the OK button.
- 3 Press / to highlight an email address, then press the OK button.  
To send the picture to more than one person, repeat step 3 for each address.

*Selected addresses are noted with a check mark, and the email icon appears with the picture.*

- 4 To remove a selection, highlight a checked address and press the OK button. To remove all email selections, select Clear All.
- 5 Highlight Exit, then press the OK button.  
*Your selections are saved.*
- 6 Press the Share button to return to Capture mode.

### Emailing Tagged Pictures

When you transfer the tagged pictures to your computer, the Kodak EasyShare software Email screen opens and lets you immediately send the pictures to the addresses you specified. See the Kodak EasyShare software Help for details on emailing.

## Tagging Pictures as Favorites



- 1 Locate a picture, then press the Share button.
- 2 Highlight Favorite ♥, then press the OK button.  
*The Favorite icon ♥ appears with the picture.*
- 3 To remove the tag, press the OK button again.
- 4 Press the Share button to return to Capture mode.


## Using Favorites on Your Computer

See the Kodak EasyShare software Help for details on retrieving and organizing Favorites on your computer.

# 5 Customizing Camera Settings—Setup Mode

Use Setup mode  to customize your camera settings. You can access Setup mode two ways: in the Capture menu screen and the Review menu screen.

In  
Capture  
mode



In  
Review  
mode



But remember, you can press the Shutter button and take a picture anytime, no matter what mode the camera is in!

## To Access Setup Mode/Menus

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup  and press the OK button.
- 3 Press the Menu button to turn off the Setup menu and return to Capture or Review mode.

### Setup Menus



[Return \(page 42\)](#)



[Default Print Quantity \(page 42\)](#)



[Quickview \(page 43\)](#)



[Liveview \(page 43\)](#)



[Date/Time \(page 7\)](#)



[Video Out \(page 44\)](#)



[Language \(page 6\)](#)



[Format \(page 45\)](#)



[About \(page 46\)](#)

## Returning to the Previous Menu

The Return feature lets you return to the menu screen from which you entered the Setup menu.



- In the Setup menu, highlight Return , then press the OK button.

*You are returned to the menu screen from which you entered Setup: Capture or Review.*

## Changing the Print Quantity Default

The Default Print Quantity setting determines the value that is displayed on the Share Print screen (see [page 38](#)). The default value is one.

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.



- 3 Highlight Default Print Quantity , then press the OK button.
- 4 Press / to indicate the new default quantity, then press the OK button.
- 5 Press the Menu button to turn off the menu.

*This setting remains until you change it.*

## Turning Off Quickview

After you take a picture, Quickview displays it on the LCD for 5 seconds (see [page 17](#)). The default setting is on. To save battery power, turn off Quickview:

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.
- 3 Highlight Quickview , then press the OK button.
- 4 Highlight Off, then press the OK button.
- 5 Press the Menu button to turn off the menu.

*The picture is not automatically displayed on the LCD after you take it.  
To see the picture, press the Review button.*

*This setting remains until you change it.*

## Turning On Liveview

The Liveview feature displays a live image on the LCD so you can frame your picture in the LCD instead of the Viewfinder (see [page 16](#)). The default setting is Off, which means that you must press the OK button to see the live image.

**IMPORTANT:** *Liveview quickly depletes battery power; use it sparingly.*

Turn on Liveview:

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.
- 3 Highlight Liveview , then press the OK button.
- 4 Highlight On, then press the OK button.

*The live image is displayed whenever the camera is on. Liveview automatically turns off after one minute to conserve battery power.  
You can manually turn it back on by pressing the OK button.*


- 5 Press the Menu button to turn off the menu.

*This setting remains until you change it.*

## Setting Video Out

The Video Out feature lets you match the camera's video signal to the standard for your location. Video Out must be set correctly to run a slide show on an external device (see [page 33](#)).

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.
- 3 Highlight Video Out , then press the OK button.



- 4 Highlight an option:  
**NTSC**—used in the United States and Japan and most countries outside of Europe.  
**PAL**—used in European countries.
- 5 Press the OK button to accept the change and return to the Setup menu.
- 6 Press the Menu button to turn off the menu.

*This setting remains until you change it.*


# Formatting Memory or MMC/SD Card



## CAUTION:

Formatting deletes everything in memory or on the card, even protected pictures and the internal email address book. Removing a card during formatting may damage the card.

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.



- 3 Highlight Format , then press the OK button.
- 4 Highlight an option:
  - CARD**—deletes everything on the card, even protected pictures, and reformats the card for use in the camera.
  - CANCEL**—exits without making a change.
  - INTERNAL**—reformats and deletes everything in internal memory, even protected pictures and the address book.
- 5 Press the OK button.
- 6 Highlight Continue, then press the OK button.  
*Once formatting begins, it is completed even if you turn off the camera or change modes.*  
*When the formatting is complete, the Setup menu is redisplayed.*
- 7 Press the Menu button to turn off the menu.

## Viewing Camera Information

The About feature displays information that is helpful if you need to call for service on your camera.

- 1 In Capture or Review mode, press the Menu button.
- 2 Highlight Setup , then press the OK button.



- 3 Highlight About , then press the OK button.  
*The camera information is view-only.*
- 4 Press the Menu button to turn off the menu.

# 6 Installing the Software

## System Requirements

### Windows System Requirements

- Personal computer for Windows 98, 98SE, ME, 2000\*, or XP\* operating systems
- 233 MHz processor or greater
- 64 MB of available RAM (128 MB for Windows XP)
- 100 MB of available hard disk space
- CD-ROM drive
- Available USB port
- Color monitor with a minimum resolution of 800 x 600 pixels; High Color (16-bit) or True Color (24-bit) recommended
- Internet access for online printing and emailing

\* For Windows 2000 and XP operating systems you must have Administrator rights to install software.

### Mac OS X System Requirements

- Power Mac G3, G4, G4 Cube; iMAC; PowerBook G3, G4; iBook computer
- Mac OS 10.1.2, minimum
- 128 MB of available RAM
- 200 MB of available hard disk space
- CD-ROM drive
- Built-in USB port
- Color monitor with a minimum resolution of 800 x 600 pixels; thousands or millions of colors recommended
- Internet access for online printing and emailing

### **Mac OS 8.6 and 9.x System Requirements**

- PowerPC-based Macintosh computer
- Mac OS 8.6/9.x
- 64 MB of available RAM
- 200 MB of available hard disk space
- CD-ROM drive
- Built-in USB port
- Color monitor with a minimum resolution of 800 x 600 pixels; thousands or millions of colors recommended
- Internet access for online printing and emailing

NOTE: Mac OS 8.6 and 9.x do not support the Share button functions.  
Mac OS X is recommended for full functionality.

## Install the Software

For information on the software applications included on the Kodak EasyShare software CD, see the Kodak EasyShare software Help.



### CAUTION:


**Do not install the Kodak EasyShare software with the camera or camera dock connected to the computer. It may cause the software to load incorrectly. If you have already connected, disconnect the camera or camera dock before you proceed.**

- 1 Before you begin, close all software applications that are open on your computer.
- 2 Place the Kodak EasyShare software CD into the CD drive.
- 3 Load the software:

**On a Windows OS-based computer**—if the install window does not appear, choose Run from the Start menu and type **d:\setup.exe** (if **d** is the drive letter that contains the CD).

**On Mac OS 8.6 and 9.x**—on the install window, click Continue.

**On Mac OS X**—double-click the CD icon on the desktop, then click the Install icon.



- 4 Follow the on-screen instructions to install the software. If prompted, restart the computer when the installation is complete.
  - Select Typical to automatically install the needed applications on Windows OS-based computers. Select Custom to choose the applications to install.
  - Select Easy to automatically install the needed applications on Macintosh computers running OS 8.6 or 9.x.
  - Follow the on-screen instructions to install the software on Macintosh computers running OS X.

NOTE: When prompted, take a few minutes to electronically register your camera and software. This lets you receive information regarding software updates and registers some of the products included with the camera. You must be connected to your Internet service provider to register electronically.

For further installation help, see the Quick Start Guide.

# 7 Connecting to the Computer


## Important—Before You Connect

Install the software from the Kodak EasyShare software CD BEFORE you connect the camera or camera dock to the computer.

## Connecting to the Computer

You can transfer your pictures from the camera to the computer using either the camera alone or the optional Kodak EasyShare camera dock or camera dock II. See [page 55](#) for connecting with a camera dock.

### Transferring Pictures With the USB Cable



- 1 Turn off the camera.
- 2 Plug the labeled (A) end of the USB cable into the labeled USB port on your computer. See your computer User's Guide for details.
- 3 Plug the other end of the USB cable into the labeled USB port on the camera.
- 4 Turn on the camera to begin transferring.  
*Kodak EasyShare software opens on your computer and prompts you through the transfer process.*

An optional AC adapter is available for your camera; it saves battery power when transferring pictures (see [page 87](#)).

**NOTE:** You can also use a Kodak multi-card reader or Kodak SD multimedia card reader-writer to transfer your pictures. See a dealer of Kodak products or visit our Web site at <http://www.kodak.com/go/cx4310accessories>.

## Transferring Pictures to Your Computer

For details on transferring pictures, see the Quick Start Guide or the Kodak EasyShare software Help.

## Printing Pictures from Your Computer

For details on printing pictures from your computer and ordering prints online, see the Kodak EasyShare software Help.

## Printing from an SD/MMC Card

- Automatically print tagged pictures when you insert your card into a printer with an SD/MMC slot. See your printer user guide for details.
- Contact your local retailer for the availability to print professionally from SD/MMC cards.
- Make your own prints at a Kodak picture maker kiosk with a built-in SD/MMC slot.

## Print With or Without a Computer


Dock your camera to the Kodak EasyShare printer dock 4000 and print directly—without using a computer. Purchase this and other accessories at a dealer of Kodak products or visit [www.kodak.com/go/cx4310accessories](http://www.kodak.com/go/cx4310accessories).

## 8 Using the Optional Camera Dock II

The Kodak EasyShare camera dock II (camera dock) makes it easy to transfer your pictures to the computer. The camera dock is also a rapid battery charger for the included Kodak EasyShare Ni-MH rechargeable battery pack, and supplies power to the camera.

To keep the battery pack charged and the camera always ready to take pictures, store your camera in the camera dock.

### Camera Dock Package Contents



- 1 Camera dock
- 2 7-volt AC power adapter  
*Some AC adapters may be different from the one pictured.*
- 3 Universal insert
- 4 Kodak EasyShare Ni-MH rechargeable battery pack
- 5 Quick Start Guide (not shown)

Purchase an optional Kodak EasyShare camera dock II at a dealer of Kodak products or visit our Web site at <http://www.kodak.com/go/cx4310accessories>.




#### CAUTION:

**Do not use the digital camera 3-volt AC adapter with a Kodak EasyShare camera dock; it is NOT compatible.**

## Installing the Camera Insert

Kodak EasyShare digital cameras are packaged with a custom camera insert, which is used to perfectly fit the camera to the camera dock.



- 1 Place the front tabs on the custom insert into the slots in the camera dock cavity.
- 2 Fit the insert down into the cavity and snap the insert into place.

### If You Do Not Have the Custom Insert

If you do not have the custom insert that was included with your camera, use the universal insert that is included with the camera dock II. The universal insert works with all Kodak EasyShare cameras, but it does not fit the cameras perfectly.


To order a custom camera insert visit our Web site at <http://www.kodak.com/go/cx4310accessories>.

## Connecting the Camera Dock

After the Kodak EasyShare software is loaded (see [page 49](#)), connect the camera dock to your computer and to an external power source. You will need:

- the USB cable included with your camera
- the 7-volt AC adapter included with the camera dock

**IMPORTANT:** *Make sure your camera is NOT in the camera dock when you are connecting to power and the computer.*




- 1 Plug the labeled (1) end of the USB cable into the labeled USB port on your computer. See your computer User's Guide for details.
- 2 Plug the other end of the USB cable into the square USB connector on the back of the camera dock.
- 3 Plug the AC adapter into the round power connector on the back of the camera dock and into a power outlet.

*Your AC adapter may be different from the one pictured or may have additional plugs. Use the plug that accommodates your type of power outlet.*

Leave the camera dock connected to the computer for easy access for transferring pictures and charging the battery pack.

**IMPORTANT:** *Use only the 7-volt AC adapter included with the camera dock. Other adapters may cause damage to your camera, camera dock, or computer.*

## Installing the Battery Pack in the Camera



- 1 Open the battery door on the bottom of the camera.
- 2 Install the battery pack as illustrated.



### CAUTION:



The battery pack can only be inserted into the camera in the orientation shown. If the battery pack does not easily install, reposition it and try again. DO NOT FORCE IT. Doing so can damage your camera.

- 3 Close the battery door.

**IMPORTANT:** *The battery pack is not charged when you receive it. See [page 58](#) for charging instructions.*

## Docking the Camera

When you are ready to transfer your pictures from the camera to the computer, or to charge the battery pack, place the camera in the camera dock.



- 1 Turn off the camera.
- 2 On the camera bottom, slide the connector cover open.
- 3 Place the camera in the camera dock and push down to seat the connectors.

***The Power/Transfer light glows green when the camera is properly seated.***

*The camera is now powered by the camera dock instead of the camera batteries.*

NOTE: If the Kodak EasyShare Ni-MH rechargeable battery pack is in the camera, the camera dock immediately begins charging (see [page 58](#)).

## Charging the Battery Pack

The battery pack is not charged when you receive it.

- 1 Turn **off** the camera.
- 2 Make sure the battery pack is installed in the camera (see [page 56](#)).
- 3 Place the camera in the camera dock (see [page 57](#)).
  - Charging begins immediately.
  - The three green charging lights monitor the charging status:



Charging Lights on Dock II


- battery low
- battery partially charged
- battery fully charged

- Full charging takes about 2.5 hours. After the battery pack is fully charged, leave the camera in the camera dock to maintain the full charge.
- Charging stops if you turn on the camera. If the camera is left in the camera dock with the power on, charging resumes when the camera enters Auto Power-off (see [page 87](#)).

NOTE: The camera dock only charges the provided Kodak EasyShare Ni-MH rechargeable battery pack. If you place the camera in the camera dock with any other type of batteries, rechargeable or not, no charging takes place.

## Transferring Pictures

To transfer pictures from your camera to your computer:



- 1 Turn off the camera and place the camera in the camera dock.
- 2 Push the Connect button.

*The Power/Transfer light blinks green while the pictures are transferring. Charging is suspended during transfer.*

*Kodak EasyShare software opens on your computer and prompts you through the transfer process.*

- 3 For details on transferring, organizing, printing, emailing, and editing your pictures, see the Kodak EasyShare software Help.


**NOTE:** When your pictures are transferred, leave the camera in the camera dock. Eight minutes after the transfer is complete, the camera dock resumes charging as necessary.

## Caution When Using a Tripod

Do not connect a tripod to the camera dock. Remove the camera from the camera dock and connect the tripod directly to the camera.

## Earlier Camera Dock Model

If you have the Kodak EasyShare camera dock, not the camera dock II, the functionality is exactly the same as described in this chapter. The only difference is that the earlier camera dock has one indicator light.



Indicator light status:

**Steady green**—camera is properly seated in the camera dock.

**Blinking green**— pictures are transferring.

**Steady red**—battery pack is charging.

**Blinking red**—error condition.

# 9 Troubleshooting

This chapter contains help for your Kodak EasyShare CX4310 digital camera or camera dock II.

Additional technical information is available in the ReadMe file located on the Kodak EasyShare software CD. For updates to Troubleshooting information, visit our Web site at <http://www.kodak.com/go/cx4310support>.

## Troubleshooting—Camera

### Camera Problems

| Camera  |   |   |
|---|---|---|
| Problem                                       | Cause   | Solution  |
| Camera does not turn on.                      | Battery is not properly installed.  | Remove and reinstall the batteries ( <a href="#">page 4</a> ).  |
|   | Battery is not charged.   | Replace or recharge the batteries ( <a href="#">page 4</a> , <a href="#">page 58</a> ).   |
|   | On/Off switch is not completely in the On position.                             | Turn the camera off then back on ( <a href="#">page 5</a> ).  |
| Camera does not turn on in cold temperatures. | The camera has been exposed to temperatures close to the lower operating range. | Remove the batteries and slowly return the camera and batteries to room temperature. Reinstall or replace the batteries ( <a href="#">page 4</a> ). |

| <b>Camera</b>                 |  |  |
|-------------------------------|--|--|
| <b>Problem</b>                | <b>Cause</b>   | <b>Solution</b>  |
| Camera does not turn off.     | Alkaline batteries were installed in the camera.                 | <p>DO NOT USE ALKALINE BATTERIES. Turn off the power switch, remove the alkaline batteries, and replace with an approved battery type (<a href="#">page 12</a>).</p> <p>If the power switch is on when you replace the batteries, the camera may not turn back on. In that case, turn the power switch off, then on.</p> |
| Shutter button does not work. | Camera is not turned on.   | Turn on the camera ( <a href="#">page 5</a> ).   |
|                               | The camera is processing a picture; the ready light is blinking. | Wait until the light stops blinking before attempting to take another picture.   |
|                               | The card or internal memory is full.                             | Transfer pictures to your computer ( <a href="#">page 52</a> ), delete pictures from the camera ( <a href="#">page 30</a> ), switch storage locations ( <a href="#">page 10</a> ), or insert a card with available memory ( <a href="#">page 9</a> ).  |

| <b>Camera</b>   |  |   |
|---|--|---|
| <b>Problem</b>  | <b>Cause</b>   | <b>Solution</b>   |
| Part of the picture is missing.   | Something was blocking the lens when the picture was taken.                            | Keep hands, fingers, or other objects away from the lens when taking pictures.  |
|   | Your eye or the picture was not centered correctly in the viewfinder.                  | Leave space around subject when centering picture in viewfinder.  |
| In Review mode, you do not see a picture on the LCD or do not see the picture you expected. | The camera may not be accessing the correct storage location.                          | Check the picture storage location setting ( <a href="#">page 10</a> ).   |
| In Review mode, pictures are displayed as black screens.                                    | The pictures were taken with a different camera or were generated with other software. | Transfer the pictures to the computer ( <a href="#">page 52</a> ), or delete the picture ( <a href="#">page 30</a> ). |
| Picture is too dark.  | Flash is not on or did not function.   | Turn on the flash ( <a href="#">page 18</a> ).  |
|   | The subject is too far away for the flash to have an effect.                           | Move so there is no more than the following distance between the camera and the subject: 9.8 ft (3 m).                |
|   | The subject is in front of a bright light (backlit).                                   | Use Fill flash ( <a href="#">page 18</a> ) or change your position so the light is not behind the subject.            |
|   | Lighting condition is too dark.  | Increase exposure compensation ( <a href="#">page 23</a> ).   |

| <b>Camera</b>   |   |   |
|---|---|---|
| <b>Problem</b>  | <b>Cause</b>  | <b>Solution</b>   |
| Camera freezes up when a card is inserted or removed.               | Camera detects an error when the card was inserted or removed.                      | Turn the camera off, then back on. Make sure the camera is turned off before inserting or removing a card.  |
| Picture is too light.   | The flash is not needed.  | Change to Auto flash ( <a href="#">page 18</a> ).   |
|   | The subject was too close when the flash was used.                                  | Move so there is at least 1.6 ft (0.5 m) between the camera and the subject.  |
|   | Lighting condition is too bright.   | Decrease exposure compensation ( <a href="#">page 23</a> ).   |
| Stored pictures are damaged.  | The card was removed when the ready light was blinking.                             | Make sure the ready light is not blinking, then turn off the camera before removing the card.   |
| Pictures remaining number does not decrease after taking a picture. | Picture does not take up sufficient space to decrease the picture remaining number. | The camera is operating normally. Continue taking pictures.   |
| Picture orientation is not accurate.                                | The camera sensed that it was rotated or tilted while the picture was taken.        | Set the Orientation Sensor ( <a href="#">page 26</a> ). Turn off the Orientation Sensor when your subject is above or below you (such as in the sky or on the floor). |

| <b>Camera</b>                                     |   |  |
|---|---|--|
| <b>Problem</b>                                    | <b>Cause</b>  | <b>Solution</b>  |
| Picture is not clear.                             | The lens is dirty.  | Clean the lens ( <a href="#">page 84</a> ).  |
|   | Subject too close when taking picture.  | Move so there is at least 11.8 in (0.3 m) between the camera and the subject; or turn on Close-up ( <a href="#">page 21</a> ). |
|   | Camera may be in Close-up ( <a href="#">page 21</a> ) and the subject is too far away for proper focus. | Turn off Close-up ( <a href="#">page 21</a> ).   |
|   | Subject or the camera moved while the picture was taken.  | Hold the camera steady while taking the picture and for at least one second after pressing the Shutter button.                 |
|   | The subject is too far away for the flash to be effective.  | Move so there is no more than the following distance between the camera and the subject: 9.8 ft (3 m).                         |
| Slide show does not run on external video device. | Video Out setting is incorrect.   | Adjust the camera Video Out setting (NTSC or PAL, <a href="#">page 44</a> ).   |
|   | External device is set incorrectly.   | Refer to the external device's user's guide.   |
| Slide show does not run on LCD screen.            | The camera may not be accessing the correct storage location.   | Check the picture storage location setting ( <a href="#">page 10</a> ).  |

## Camera/Computer Communications

| <b>Camera Communications</b>                     |  |  |
|--|--|--|
| <b>Problem</b>                                   | <b>Cause</b>   | <b>Solution</b>  |
| The computer cannot communicate with the camera. | There is a problem with the configuration of the USB port on your computer.                  | See the following file on the Kodak EasyShare software CD: USB.html<br>Or, go to: <a href="http://www.kodak.com/go/camerasureport">www.kodak.com/go/camerasureport</a> |
|  | Camera power is off.   | Turn on the camera ( <a href="#">page 5</a> ).   |
|  | Battery is not charged.  | Replace or recharge the batteries ( <a href="#">page 4</a> , <a href="#">page 58</a> ).  |
|  | Some Advanced Power Management utilities on laptops can turn off ports to save battery life. | See the Power Management section of your laptop user's guide to disable this feature.  |
|  | Software is not installed.   | Install the software ( <a href="#">page 49</a> ).  |
|  | USB cable is not securely connected.   | Connect cable to camera and computer port ( <a href="#">page 51</a> ).   |
|  | There are too many applications running on your computer.                                    | Disconnect your camera from the computer. Close all software applications, reconnect your camera and try again.  |
|  | The Battery Monitor or similar software runs constantly.                                     | Close that software before starting the Kodak software.  |

| <b>Camera Communications</b>   |   |   |
|--|---|---|
| <b>Problem</b>   | <b>Cause</b>  | <b>Solution</b>   |
| Cannot transfer pictures to computer. The Add New Hardware Wizard cannot locate drivers. | Software is not installed on computer.                    | <ul style="list-style-type: none"> <li><input type="radio"/> Disconnect USB cable, or camera dock, from computer.</li> <li><input type="radio"/> Install Kodak EasyShare software (<a href="#">page 49</a>).</li> </ul>   |
| Cannot transfer pictures to computer.  | Software is not fully or correctly installed on computer. | <ul style="list-style-type: none"> <li><input type="radio"/> Disconnect USB cable, or camera dock, from computer.</li> <li><input type="radio"/> Uninstall the software: Start→Settings→Control Panel→Add/Remove Programs</li> <li><input type="radio"/> Re-install Kodak EasyShare software (<a href="#">page 49</a>).</li> <li><input type="radio"/> See the Kodak Web site devoted to installing the Kodak EasyShare software on various operating systems (<a href="#">page 77</a>).</li> </ul> |

## SD/MMC Cards

| <b>SD/MMC Card</b>                                    |  |  |
|---|--|--|
| <b>Problem</b>  | <b>Cause</b>   | <b>Solution</b>  |
| The camera does not recognize your SD/MMC card.       | The card may not be SD/MMC certified.                          | Purchase a certified SD/MMC card ( <a href="#">page 9</a> ).   |
|   | The card may be corrupt.                                       | Reformat the card ( <a href="#">page 45</a> ).<br>Caution: Formatting erases all pictures from the card. |
|   | No card is inserted in camera or card is not fully inserted.   | Insert a card into the card slot, then push to seat the connector ( <a href="#">page 9</a> ).            |
| Camera freezes up when a card is inserted or removed. | Camera detects an error when the card was inserted or removed. | Turn the camera off, then back on.<br>Make sure the camera is off when inserting or removing a card.     |


## Camera LCD Messages

| <b>LCD Messages</b>  |   |   |
|--|---|---|
| <b>Message</b>   | <b>Cause</b>  | <b>Solution</b>   |
| No images to display   | There are no pictures in the current storage location.                                      | Change your picture storage location setting ( <a href="#">page 10</a> ).                                       |
| Memory card requires formatting  | The card is corrupted or formatted for another digital camera.                              | Insert a new card or format the card ( <a href="#">page 45</a> ).   |
| Memory card cannot be read (Please format memory card or insert another memory card) |   |   |
| Internal memory requires formatting  | The camera internal memory is corrupted.  | Format the internal memory ( <a href="#">page 45</a> ).   |
| Internal memory cannot be read (Please format internal memory)                       |   |   |
| No memory card, Files not copied   | There is no card in the camera. Your pictures were not copied.                              | Turn off the camera and insert a card.  |
| Not enough space to copy files   | There is not enough space in the location you are copying to (internal memory or the card). | Delete pictures from the location you are copying to ( <a href="#">page 30</a> ), or insert a new card.         |
| Read only memory card, change to internal memory to capture                          | The card in the camera is write-protected.  | To take a picture, insert a new card or change storage location to internal memory ( <a href="#">page 10</a> ). |

| <b>LCD Messages</b>                                   |  |   |
|---|--|---|
| <b>Message</b>  | <b>Cause</b>   | <b>Solution</b>   |
| Memory card is protected<br>Reset switch on card      | Switch on card is in write-protect position.   | Reset the switch as shown on LCD.   |
| Card is locked  | The card in the camera is write-protected.   | To take a picture, insert a new card or change storage location to internal memory ( <a href="#">page 10</a> ).   |
| Date/Time entry screen appears automatically          | This is the first time you turned on the camera; or the batteries have been removed for an extended period of time; or the batteries are exhausted.        | Reset the clock ( <a href="#">page 7</a> ).   |
| High camera temperature. (Camera will be turned off.) | The internal temperature of the camera is too high for the camera to operate. The viewfinder light glows red and the camera will turn off in five seconds. | Leave the camera off for several minutes, then turn it back on.<br><br>If the message reappears, repeat the sequence above until the message does not appear. |
| Memory Card is full                                   | There is no more space on the card in the camera.  | Delete pictures from the card ( <a href="#">page 30</a> ), insert a new card, or change storage location to internal memory ( <a href="#">page 10</a> ).      |

| <b>LCD Messages</b>  |   |  |
|--|---|--|
| <b>Message</b>   | <b>Cause</b>  | <b>Solution</b>  |
| Internal Memory is full  | There is no more space in the camera's internal memory.     | Delete pictures from the internal memory ( <a href="#">page 30</a> ) or change storage location to Auto and insert card ( <a href="#">page 10</a> ). |
| Unrecognized File Format   | The camera cannot read the picture format.                  | Transfer the unreadable picture to the computer ( <a href="#">page 52</a> ), or delete the picture ( <a href="#">page 30</a> ).                      |
| No Address Book in Camera (Connect with computer to import address book) | No email addresses appear because there is no address book. | Create and copy address book from your computer. See Kodak EasyShare software Help.  |

## Camera Ready Light Status



### Camera Ready Light

| Light Status   | Cause   | Solution  |
|--|---|---|
| Ready light does not turn on and the camera does not work. | Camera is not turned on.                          | Turn on the camera ( <a href="#">page 5</a> ).  |
|  | Batteries are exhausted.                          | Replace or recharge the batteries ( <a href="#">page 4</a> , <a href="#">page 58</a> ). |
|  | Power switch was on when batteries were reloaded. | Turn camera off, then back on.  |
| Ready light glows steady green.                            | Camera is on; ready to take a picture.            | The camera is operating normally.   |
| Ready light blinks red.                                    | Batteries are low or exhausted.                   | Replace or recharge the batteries ( <a href="#">page 4</a> , <a href="#">page 58</a> ). |


| <b>Camera Ready Light</b>     |   |  |
|-------------------------------|---|--|
| <b>Light Status</b>           | <b>Cause</b>  | <b>Solution</b>  |
| Ready light glows steady red. | Camera's internal memory or card is full.           | Transfer pictures to your computer ( <a href="#">page 52</a> ), delete pictures from the camera ( <a href="#">page 30</a> ), switch storage locations ( <a href="#">page 10</a> ), or insert a card with available memory. |
|                               | Camera processing memory is full.                   | Wait. Resume picture taking when the light turns green.  |
|                               | Your card is read-only.                             | Change your storage location to internal memory (see <a href="#">page 10</a> ), or use a different card.   |
| Ready light blinks green.     | Picture is being processed and saved to the camera. | Camera is operating normally.  |
| Ready light blinks orange.    | Flash is not charged.                               | Wait. Resume picture taking when the light stops blinking and turns green.   |
|                               | Auto exposure or auto focus are not locked.         | Release the Shutter button and recompose the picture.  |

# Troubleshooting—Camera Dock II

## Camera Dock II Problems

| <b>Camera Dock</b>                           |  |   |
|--|--|---|
| <b>Problem</b>                               | <b>Cause</b>   | <b>Solution</b>   |
| Pictures are not transferred to the computer | AC adapter or USB cable is not securely connected.               | Check the connections ( <a href="#">page 55</a> ).                  |
|  | Software is not installed.                                       | Install the software ( <a href="#">page 49</a> ).                   |
|  | There are too many applications running on your computer.        | Close all software applications and try again.                      |
|  | Camera was removed from the camera dock during picture transfer. | Replace the camera on the camera dock and press the Connect button. |
|  | Connect button was not pressed.                                  | Press the Connect button.   |

## Camera Dock II Light Status



| <b>Camera Dock Power/Transfer Light</b> |   |   |
|---|---|---|
| <b>Light Status</b>                     | <b>Cause</b>                                    | <b>Comment</b>  |
| Light glows steady green                | Camera is properly seated in the camera dock.   | The camera and camera dock are operating normally.            |
| Light blinks green                      | Pictures are being transferred to the computer. |   |
| Light is off                            | Camera is not properly seated in camera dock.   | Remove the camera and re-seat it ( <a href="#">page 57</a> ). |

| <b>Camera Dock Charging Lights</b>   |                           |  |
|--|---------------------------|--|
| <b>Light Status</b>  | <b>Cause</b>              | <b>Comment</b>   |
| <br>No lights | Charging has not started. | The camera is not in the camera dock.<br><br>Camera is turned on. Turn off to begin charging.<br><br>Battery in camera is not a Kodak EasyShare Ni-MH rechargeable battery pack. |

**Camera Dock Charging Lights**

| <b>Light Status</b>   | <b>Cause</b>                  | <b>Comment</b>                                     |
|---|-------------------------------|--|
|  One green light    | Battery is low.               | The camera and camera dock are operating normally. |
|  Two green lights   | Battery is partially charged. |  |
|  Three green lights | Battery is fully charged.     |  |

**Camera Dock Error Light**

| <b>Light Status</b>   | <b>Cause</b>   | <b>Comment</b>   |
|---|--|--|
|  One blinking red light | Battery pack is installed incorrectly.   | Reinstall the battery pack ( <a href="#">page 56</a> ).                                |
|   | The battery pack or connector pins are damaged.                                  | Check for damage.  |
|   | The camera and battery pack have been exposed to very high or low temperatures.  | Slowly return the camera and battery pack to room temperature.                         |
|   | Battery in camera is not rechargeable or no battery pack is installed in camera. | Install a Kodak EasyShare Ni-MH rechargeable battery pack ( <a href="#">page 56</a> ). |

# 10 Getting Help

## Helpful Web Links

|   |  |
|---|--|
| <a href="http://www.kodak.com/go/pcbasics">http://www.kodak.com/go/pcbasics</a>                           | For help navigating through a Windows OS-based computer and working with digital pictures. |
| <a href="http://www.kodak.com/go/cx4310support">http://www.kodak.com/go/cx4310support</a>                 | For help with your Kodak EasyShare CX4310 digital camera.                                  |
| <a href="http://www.kodak.com/go/cx4310downloads">http://www.kodak.com/go/cx4310downloads</a>             | To download the latest camera software and firmware.                                       |
| <a href="http://www.kodak.com/go/onetouch">http://www.kodak.com/go/onetouch</a>                           | To optimize your printer for prints with truer, vibrant colors.                            |
| <a href="http://www.kodak.com/go/camerasupport">http://www.kodak.com/go/camerasupport</a>                 | For product support on cameras, software, accessories, and more.                           |
| <a href="http://www.kodak.com/go/cx4310accessories">http://www.kodak.com/go/cx4310accessories</a>         | To purchase a full range of digital camera accessories.                                    |
| <a href="http://www.kodak.com/go/EasyShareSWHelpWin">http://www.kodak.com/go/EasyShareSWHelpWin</a>       | To get help installing the Kodak EasyShare software.                                       |
| <a href="http://www.kodak.com/go/EasyShareSWHelpMacOS9">http://www.kodak.com/go/EasyShareSWHelpMacOS9</a> |  |
| <a href="http://www.kodak.com/go/EasyShareSWHelpMacOSX">http://www.kodak.com/go/EasyShareSWHelpMacOSX</a> |  |
| <a href="http://www.kodak.com/go/register">http://www.kodak.com/go/register</a>                           | To register your new Kodak EasyShare CX4310 digital camera.                                |

## Help in this User Guide

See [Chapter 9, Troubleshooting](#), for help with problems you may have with your camera, camera/computer connections, camera dock, or SD/MMC cards.

## Software Help

For help with the software included on the Kodak EasyShare software CD, see the Quick Start Guide or the Kodak EasyShare software Help.

## Telephone Customer Support

If you have questions concerning the operation of the software or camera, you may speak directly to a customer support representative.

Customer support hours vary by location.

### Before You Call

Before you call to speak to a customer support representative, please have the camera connected to your computer, be at your computer, and have the following information available:

Operating system \_\_\_\_\_

Processor speed (MHz) \_\_\_\_\_

Computer model \_\_\_\_\_

Amount of memory (MB) \_\_\_\_\_

Exact error message you received \_\_\_\_\_

Version of installation CD \_\_\_\_\_

Camera serial number \_\_\_\_\_

## Telephone Numbers

|                       |                  |
|-----------------------|------------------|
| Australia             | 1800 147 701     |
| Austria/Osterreich    | 0179 567 357     |
| Belgium/Belgique      | 02 713 14 45     |
| Brazil                | 0800 150000      |
| Canada                | 1 800 465 6325   |
| China                 | 800 820 6027     |
| Denmark/Danmark       | 3 848 71 30      |
| Ireland/Eire          | 01 407 3054      |
| Finland/Suomi         | 0800 1 17056     |
| France                | 01 55 1740 77    |
| Germany/Deutschland   | 069 5007 0035    |
| Greece                | 00800 441 25605  |
| Hong Kong             | 800 901 514      |
| India                 | 91 22 617 5823   |
| Italy/Italia          | 02 696 33452     |
| Japan                 | 81 3 5644 5500   |
| Korea                 | 0798 631 0024    |
| Netherlands/Nederland | 020 346 9372     |
| New Zealand           | 0800 440 786     |
| Norway/Norge          | 23 16 21 33      |
| Philippines           | 1 800 1 888 9600 |
| Portugal              | 021 415 4125     |
| Singapore             | 800 6363 036     |

|                               |                  |
|-------------------------------|------------------|
| Spain/España                  | 91 749 76 53     |
| Sweden/Sverige                | 08 587 704 21    |
| Switzerland/Schweiz/Suisse    | 01 838 53 51     |
| Taiwan                        | 0080 861 008     |
| Thailand                      | 001 800 631 0017 |
| UK                            | 0870 243 0270    |
| United States                 | 1 800 235 6325   |
| Outside the United States     | 585 726 7260     |
| International Toll Line       | +44 131 458 6714 |
| International Toll Fax Number | +44 131 458 6962 |

These telephone numbers change occasionally. For the most up-to-date listings, visit: <http://www.kodak.com/US/en/digital/contacts/DAIInternationalContacts.shtml>.

# 11 Appendix

This appendix serves as a resource for technical information about your Kodak EasyShare CX4310 digital camera, Kodak EasyShare camera dock II, SD/MMC cards, batteries, and available accessories.

## Camera Specifications

| Specifications—Kodak EasyShare CX4310 digital camera |                                   |  |
|--|-----------------------------------|--|
| Pixel Resolution<br>(by Quality setting)             | Best - 3.2 MP, low compression    | 2080 x 1544, 1/5 JPEG compressed                               |
|  | Better - 3.2 MP, high compression | 2080 x 1544, 1/10 JPEG compressed                              |
|  | Good - 0.8 MP                     | 1024 x 768, 1/5 JPEG compressed                                |
| Color  |                                   | 24-bit, millions of colors                                     |
| Picture File Format                                  |                                   | EXIF 2.2 (JPEG compression)                                    |
| Picture Storage                                      |                                   | 16 MB internal memory<br>MMC (MultiMedia) or SD card, optional |
| Viewfinder   |                                   | Optical—Reverse Galilean                                       |
| ISO Sensitivity                                      |                                   | 100  |
| Flash Range  |                                   | 1.6 to 9.8 ft (0.5 to 3 m)                                     |
| Tripod Socket  |                                   | .25 in. (6 mm) threaded  |
| Video Out  |                                   | NTSC or PAL  |
| Operating Temperature                                |                                   | 32 to 104° F (0 to 40° C)                                      |

**Specifications—Kodak EasyShare CX4310 digital camera**

|            |                                   |  |
|------------|-----------------------------------|--|
| Power      | Batteries                         | 2 Ni-MH, AA rechargeable<br>2 Kodak AA digital camera batteries<br>Kodak CRV3 lithium battery<br>2 Lithium, AA<br>Alkaline batteries not recommended |
|            | Battery pack,<br>camera dock only | Kodak EasyShare Ni-MH rechargeable<br>battery pack, recharge in camera dock<br>only.<br>Dock provides power to the camera.                           |
|            | 3V, DC power in                   | Optional AC adapter available (see<br><a href="#">page 87</a> )  |
| Lens       | Type                              | Optical quality glass  |
|            | Maximum<br>Aperture               | f/3.5  |
|            | Zoom, 2X                          | 2X Digital zoom  |
|            | Focal Length                      | 36 mm (equivalent to 35 mm camera)   |
|            | Focus Distance                    | 11.8 in. (300 mm) to infinity  |
|            | Focus Distance,<br>Close-Up       | 5.9 to 19.7 in. (150 to 500 mm)  |
| Dimensions | Width                             | 4.3 in. (109 mm)   |
|            | Length                            | 1.6 in. (41 mm)  |
|            | Height                            | 2.6 in. (66 mm)  |
| Weight     |                                   | 7.1 oz (200 g) without batteries or card   |

## Original Factory Settings—Camera

| Feature               | Factory Setting              |
|-----------------------|------------------------------|
| Date/Time             | 2001/1/1; 12:00              |
| Date Stamp            | Off                          |
| Exposure Compensation | 0                            |
| Flash                 | Auto                         |
| Image Storage         | Auto                         |
| Liveview              | Off                          |
| Orientation Sensor    | On                           |
| Print Quantity        | 1                            |
| Quality               | Best 3.2 MP, low compression |
| Quickview             | On                           |
| Self Timer            | Off                          |
| Slide Show Interval   | 5 seconds                    |
| Video Out             | NTSC                         |

## Upgrading Your Software and Firmware

Take advantage of the latest enhancements to your Kodak software and camera firmware. Software refers to the applications included on the Kodak EasyShare software CD. Camera firmware is the internal software that runs on the camera.

To download the latest versions of software and firmware, go to: <http://www.kodak.com/go/cx4310downloads>

## Tips, Safety, Maintenance

- Always follow basic safety precautions. Refer to the “Important Safety Instructions” booklet packed with your camera.
- Do not allow any chemicals, such as suntan lotion, to come into contact with the painted surface of the camera.
- If the camera has been subjected to inclement weather or you suspect water has gotten inside the camera, turn off the camera and remove the battery and card. Allow all components to air-dry for at least 24 hours before using the camera again.
- Clean the lens and LCD:
  - 1 Blow gently on the lens or LCD to remove dust and dirt.
  - 2 Moisten the lens or LCD by breathing lightly on it.
  - 3 Wipe the lens or LCD gently with a soft, lint-free cloth or an untreated lens-cleaning tissue.

Do not use cleaning solutions unless they are designed specifically for camera lenses. **Do not wipe the camera lens or LCD with chemically treated eyeglass lens tissue. It may scratch the lens.**
- Clean the outside of the camera by wiping with a clean, dry cloth. Never use harsh or abrasive cleaners or organic solvents on the camera or any of its parts.
- Service agreements are available in some countries. Please contact a dealer of Kodak products for more information.
- For digital camera disposal or recycling information, please contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at [www.eiae.org](http://www.eiae.org) or the Kodak Web site at [www.kodak.com/go/cx4310support](http://www.kodak.com/go/cx4310support).

## Picture Storage Capacities

Picture file sizes can vary. You may be able to store more or fewer pictures. Purchase cards on our Web site at <http://www.kodak.com/go/cx4310accessories>.

|                              | Store this many pictures at: |           |        |
|------------------------------|------------------------------|-----------|--------|
|                              | Best ★★★                     | Better ★★ | Good ★ |
| <b>16 MB internal memory</b> | 14                           | 29        | 59     |
| <b>8 MB MMC/card</b>         | 7                            | 14        | 29     |
| <b>16 MB card</b>            | 14                           | 29        | 59     |
| <b>32 MB card</b>            | 29                           | 59        | 120    |
| <b>64 MB card</b>            | 59                           | 120       | 240    |
| <b>96 MB card</b>            | 90                           | 180       | 360    |
| <b>192 MB card</b>           | 180                          | 360       | 720    |

## Locating Pictures on an MMC/SD Card

Pictures stored on MMC/SD Cards use a standard agreed upon by many camera manufacturers. This lets you use the cards in different cameras. If you use a card reader to retrieve your files, the following description of the card file structure may be helpful.

**MISC folder**—contains the order files created when you use the Share feature to tag files for printing, emailing, and as Favorites.

**SYSTEM folder**—used for updating camera firmware.

**DCIM folder**—root level folder, contains the 100K4310 folder. Each time you turn on the camera or insert a different card, any empty folders within the DCIM folder are removed.

**100K4310 subfolder**—contains all the pictures on the card.

## Card File Naming Conventions

- Pictures are named DCP\_nnnn.JPG, and are numbered in the order in which they are taken. The first picture is named DCP\_0001.JPG; the highest number allowed is DCP\_9999.JPG.
- When a card contains a picture named DCP\_9999.JPG in the \DCIM\100K4310 folder, subsequent pictures appear in a new folder (\DCIM\101K4310), beginning with picture DCP\_0001.JPG.
- Even if you transfer pictures to the computer or delete pictures from the camera, the camera continues to use consecutive numbers for all subsequent pictures. For example, if the last picture taken was DCP\_0007.JPG and you delete it, the next picture you take is named DCP\_0008.JPG.
- When you insert a different card into your camera, the next picture number is defined by incrementing the higher of the last picture taken by the camera, or the highest existing picture number in the folder.
- If you use the card in a camera other than the Kodak EasyShare CX4310 digital camera, and that camera manufacturer adheres to this file structure standard, the \DCIM folder contains a folder named by that camera. For more information, refer to the documentation that accompanied that camera.


## Battery-Saving Features

The LCD or camera turn off when the camera has been inactive.

| Camera state                              | If no activity, LCD turns off after: | If no activity, camera turns off after: | To reactivate camera:        |
|---|--------------------------------------|---|------------------------------|
| LCD Off                                   | N/A                                  |   |                              |
| LCD On; Liveview, Review, any menu screen | 1 minute                             | 8 minutes<br>(Auto Power-off)           | Press any button             |
| Quickview on                              | 5 seconds                            |   |                              |
| Slide show                                | 1 minute after slide show ends       |   |                              |
| Any state                                 | N/A                                  | 1 hour<br>(Camera off)                  | Turn power switch off and on |

## Optional AC Adapter

To save battery power, purchase a Kodak 3-volt AC adapter on our Web site at <http://www.kodak.com/go/cx4310accessories>.



- Use the 3-volt AC adapter when reviewing, copying, and transferring pictures.
- Connect the 3-volt AC adapter to the camera's DC-in port and to a power outlet.



### CAUTION:

**Do not use the 3-volt AC adapter with a Kodak EasyShare camera dock; it is NOT compatible.**

## Camera Dock II Specifications

| <b>Specifications—Kodak EasyShare camera dock II</b> |                        |  |
|--|------------------------|--|
| Communication with computer                          | USB                    | Cable included with Kodak EasyShare cameras        |
| Dimensions<br>(without insert)                       | Width/Depth/<br>Height | 5.9 in. /4.1 in. /1.4 in.<br>(150 mm/104 mm/35 mm) |
|  | Weight                 | 5.5 oz (156 g)                                     |
| Indicator lights                                     | Power/<br>Transfer     | Indicates operating/transferring pictures          |
|  | Charging, 3<br>lights  | Indicate charging and error conditions             |
| Input voltage  |                        | 7 ±0.7 V DC  |
| Power  | DC input               | AC adapter included with camera dock               |

## FCC Compliance and Advisory

Kodak EasyShare CX4310 digital camera  
Tested to comply with FCC Standards.  
FOR HOME OR OFFICE USE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

### Canadian DOC Statement

**DOC Class B Compliance**—This Class B digital apparatus complies with Canadian ICES-003.

**Observation des normes-Class B**—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



# Index

## A

about

- camera information, 46
- picture information, 35

AC adapter, optional, 87

accessories

- battery, 13
- printer dock, 52

accessories, buying, 77

adjusting

- exposure, 23
- picture quality,
- resolution, 24

alkaline batteries, warning, 4

arrow button, 5

auto

- flash, 18
- power-off, 87
- storage location, 10

## B

backlit scenes, 23

batteries

- alkaline warning, 4
- capacities, 12
- charging battery pack, 58

expected life, 12

extending life, 13

loading, 4

loading battery pack, 56

power level icon, 27

power status, 8

replacement types, 12

safety, 13

buttons, camera, ii

## C

cables

- power, camera dock, 55
- power, camera optional, 87
- USB, connect camera, 51
- USB, connect dock, 55
- video, 33

camera dock

- charging battery pack, 58
- docking camera, 57
- earlier model, 60
- installing insert, 54
- lights status, 75
- package contents, 53
- power connection, 55
- specifications, 88

- transferring pictures, 59  
USB connection, 55  
using, 53
- Canadian compliance, 89
- cap, lens, 3
- capacity
- internal memory/cards, 85
- capture mode
- accessing menus, 20
  - overview, 11
  - returning from other modes, 20
  - taking pictures, 15
- card, memory, 9, 10, 85, 86
- caring for your camera, 84
- changing storage location, 10
- charging battery pack, 58
- charging lights, camera dock II, 58, 75
- cleaning camera, lens, 84
- clock, setting, 7
- close-up scenes, 21
- communication problems, 66
- compensation, exposure, 23
- computer
- connecting camera, 51
  - connecting camera dock, 55
  - system requirements, 47
  - transferring pictures, 52, 59
- connecting the camera
- first, important note, 51
  - to camera dock, 57
  - to computer, USB cable, 51
- connecting the camera dock, 55
- contents
- camera dock package, 53
  - camera package, 2
- copying pictures
- memory to card, 34
  - to computer, 52, 59
- CRV3 battery, installing, 4
- custom insert, 54
- customer support numbers, 78
- customizing camera settings, 41
- D**
- date
- imprinting on pictures, 25
  - setting, 7
- date stamp, 25
- DCIM folder, card, 85
- defaults
- changing print quantity, 42
  - original factory settings, 83
- delete button, ii
- deleting
- by formatting, 45
  - during quickview, 17

- last picture, 17  
pictures, 30  
protected pictures, 31  
digital pictures, using, 52  
digital zoom, 19  
display problems, 63  
displaying pictures, 27  
distance limits, close-up, 21  
dock  
    printer, 52  
dock insert  
    custom, 2  
    universal, 54  
dock, camera. See camera dock  
downloading  
    pictures, 52, 59  
    software/firmware, 83
- E**
- EasyShare software,  
    installing, 49  
email icon, 27  
emailing pictures, 39  
error light, camera dock, 76  
error messages, 69  
exposure, adjusting, 23  
external video device  
    setting video out, 44
- viewing pictures on, 33
- F**
- favorites  
    icon, 27  
    tagging for, 40  
FCC compliance, 89  
features, camera overview, i—ii  
file names, card, 86  
fill flash, 18  
firmware  
    upgrading, 77, 83  
    version, 46  
flash button, ii  
flash, setting, 18  
focus distance, close-up, 21  
folders, card, 85  
formatting, memory/cards, 45  
four-way arrow button, 5
- G**
- guidelines, battery, 13
- H**
- help  
    software, 78  
    telephone support, 78  
troubleshooting

- camera, 61—73  
troubleshooting camera dock, 74—76  
web links, 77  
with computers, 77
- I**  
icons  
    camera status, 8  
    capture menus, 20  
    picture information, 27  
    review menus, 28  
    setup menus, 41  
    share menus, 37  
image storage menu, 10  
information  
    about camera, 46  
    about pictures, 35  
    product support, 77  
insert, for camera dock  
    custom, 54  
    universal, 53, 54  
installing  
    batteries, 4  
    battery pack, 56  
    insert, camera dock, 54  
    MMC/SD card, 9  
    software, 49
- internal memory  
    change storage location, 10  
    format, 45  
internet, helpful web links, 77
- K**  
Kodak digital camera batteries, 4  
Kodak EasyShare software, 52  
Kodak software  
    getting help, 52, 78  
    installing, 49  
    transferring pictures, 52  
Kodak web sites, 77
- L**  
language, setting, 6  
large print, this user guide, 1  
LCD (Liquid Crystal Display)  
    display languages, 6  
    error messages, 69  
    picture location icon, 8  
    reviewing last picture, 17  
    status bar, 8  
    turning off quickview, 43  
    turning on liveview, 43  
    using as viewfinder, 16  
    viewing pictures, 29  
lens

- cleaning, 84
  - specifications, 82
  - lens cap, 3
  - lights
    - camera dock, 60
    - camera dock II, 58, 75—76
    - ready, camera, 15, 72
    - self timer, camera, i, 22
  - links, world wide web, 77
  - liveview
    - turning on, 43
    - using LCD as viewfinder, 16
  - loading
    - batteries, 4
    - battery pack, 56
    - insert, camera dock, 54
    - MMC/SD card, 9
    - software, 49
  - loop, slide show, 32
- M**
- Macintosh
    - installing software on, 49
    - system requirements, 47, 48
  - magnify picture, 30
  - maintenance, camera, 84
  - memory
    - internal or card, 10
    - storage location setting, 10
- memory card
    - inserting, 9
    - storage capacities, 85
  - menu button, ii
  - menus
    - capture mode, 20
    - image storage, setting, 10
    - review mode, 28
    - setup mode, 41
    - share mode, 37
    - tagging pictures, 37
    - taking pictures, 20
  - MISC folder, card, 85
  - MMC/SD card
    - file name conventions, 86
    - file structure, 85
    - formatting, 45
    - inserting, 9
    - picture location, 10
    - printing from, 52
    - setting storage location, 10
    - storage capacities, 85
  - troubleshooting
    - problems, 68
  - mode indicator icon, 27
  - modes
    - camera, overview, 11
    - capture, 15, 20
    - review, 27

setup, 41  
share, 37  
monitor, requirements, 47  
multi-up, viewing thumbnails, 29

**N**

NTSC, video out setting, 44

**O**

OK button, ii, 5  
on/off switch, i, 5  
orientation sensor, 26  
overview  
    camera features, i—ii  
    camera modes, 11

**P**

package contents  
    camera, 2  
    camera dock, 53  
PAL, video out setting, 44  
picture information icons, 27  
pictures  
    close-ups, 21  
    copying, 34  
    date imprint, 25  
    deleting, 30  
    downloading, 52, 59  
    e-mailing, tagged, 39

file naming, 86  
information, viewing, 35  
locating on card, 86  
magnifying, 30  
printing, 52  
printing tagged, 38  
protecting, 31  
quality settings, 24  
reviewing, 17, 27  
status info, 27  
storage capacity, 85  
storage location, 10  
tagging, 38, 39, 40  
taking, 15  
transferring to  
    computer, 52, 59  
using on computer, 52  
viewing, 29, 33

power  
    battery status, 8  
    camera dock, 55  
    optional AC adapter,  
        camera, 87  
    turning camera on, 5  
power light, camera dock, 75  
powerdown, automatic, 87  
print icon, 27  
print sizes, per quality setting, 24  
printer dock, 52

**p**  
printing

- changing default quantity, 42
- from a card, 52
- optimizing printer, 77
- pictures, 52
- tagged pictures, 38
- this user guide, 1
- without a computer, 52

**p**  
protect icon, 27**q**  
protecting pictures, 31**Q**

## quality

- print with digital zoom, 19
- settings, 24, 85

**q**  
quickview

- deleting pictures, 17
- reviewing last picture, 17
- turning off, 43

**R**

## readme file, 61

## ready light

- status, 72
- taking pictures, 15

## red-eye, flash, 18

## register your camera, web, 77

## regulatory information, 89

## removeable memory card, 9

**r**  
requirements

- Mac OS, 47, 48
- Windows OS-based, 47

## resolution, setting, 24

## return to previous menu, 42

## review button, ii

## review mode

- getting there, 27
- menus, 28
- overview, 11
- picture information, 27
- reviewing pictures, 27

## reviewing pictures

- as you take them, 17
- deleting, 30
- magnifying, 30
- on LCD, 29
- picture information, 35
- protecting, 31
- slide show, 31

## running slide show, 31

**S**

## safety, 84

- batteries, 13

## SD card, inserting, 9

## self timer, 22

## service and support, 78

## setting

- clock, 7
- date and time, 7
- flash, 18
- language, 6
- NTSC/PAL, 44
- picture quality, 24
- picture storage location, 10
- resolution, 24
- self timer, 22
- video out, 44
- setup mode
  - getting there, 41
  - overview, 11
  - returning to previous, 42
  - using, 41
- share button, ii
- share mode
  - email tagging, 39
  - getting there, 37
  - overview, 11
  - print tagging, 38
  - tagging favorites, 40
- shutoff, auto, 87
- shutter button
  - location, ii
  - problems, 62
  - self timer delay, 22
  - taking pictures, 15
- sleep mode, 87
- slide show
  - continuous loop, 32
  - problems, 65
  - running, 31
- software
  - help, 52, 78
  - installing, 49
  - upgrading, 77, 83
- specifications
  - camera, 81
  - camera dock II, 88
  - Mac OS, 47, 48
  - Windows OS-based, 47
- status, camera, 8
- storage capacity, memory, 85
- storage location, 10
- strap, wrist, 3
- support, technical, 77—80
- system folder, card, 85
- system requirements
  - Mac OS, 47, 48
  - Windows OS-based, 47

## T

- tagging pictures
  - for email, 39
  - for favorites, 40
  - for print, 38
  - print quantity default, 42

- share mode, 37  
when and where, 37
- taking pictures  
capture mode, 15  
changing options, 20—26  
close-up, 21  
menus, 20  
self timer, 22  
setting quality, 24  
using LCD as viewfinder, 16
- telephone support, 78
- television, viewing pictures, 33
- thumbnails, viewing on LCD, 29
- time, setting, 7
- timer, shutter delay, 22
- tips  
battery guidelines, 13  
maintenance, 84  
readme file, 61  
safety, 84
- transfer light, camera dock, 75
- transferring pictures to  
computer, 52, 59
- trash can, deleting, 17, 30
- tripod, connecting, i, 59
- troubleshooting problems  
camera, 61—73  
camera dock, 74—76  
camera dock lights, 75—76
- camera ready light, 72  
communications, 66  
error messages, 69  
SD/MMC card, 68
- turning camera on and off, 5
- U**
- universal insert, 54
- upgrading software,  
firmware, 83
- URLs, Kodak web sites, 77
- USB cable, connector, i, 51, 55
- V**
- video out, setting, 33, 44
- viewfinder  
lens, i  
taking pictures, 15  
using LCD instead, 16
- viewing  
camera information, 46  
picture information, 35
- viewing picture  
after taking, 17  
magnified, 30  
on an external device, 33  
on LCD, 29

**W**

web links, 77

Windows

installing software, 49

system requirements, 47

wrist strap, attaching, 3

**Z**

zoom

button, ii, 5

optical, digital, 19