

OLYMPUS®


DIGITAL CAMERA

Stylus 710/*μ* 710

Stylus 700/*μ* 700

Advanced Manual

Detailed explanations of all the functions including camera buttons and menus are provided. Use them according to your purpose.



- Thank you for purchasing an Olympus digital camera. Before you start to use your new camera, please read these instructions carefully to enjoy optimum performance and a longer service life. Keep this manual in a safe place for future reference.
- We recommend that you take test shots to get accustomed to your camera before taking important photographs.
- In the interest of continually improving products, Olympus reserves the right to update or modify information contained in this manual.
- The screen and camera illustrations shown in this manual were produced during the development stages and may differ from the actual product. Unless otherwise specified, the explanation about these illustrations is provided in Stylus710/*μ*710.

How to use this manual

Search for a topic ▶▶▶ Table of Contents



 P. 3

Contents

How to use this manual	2
Contents	3

1 Button operations 8
















Test out the functions of the camera buttons by following the illustrations and actually trying them out on the camera.

POWER button	Turning the camera on and off	8
Shutter button	Shooting pictures	8
Mode dial	Switching between shooting and playback modes	9
	Shooting still pictures	9
	Shooting pictures using image blur reduction	9
SCN	Shoot pictures by selecting a scene according to the situation	9

Search for a term ▶▶▶ Index

 P. 83

Index

 Red-eye reduction flash	13	Battery compartment/card cover	78
 Fill-in flash	13	BEEP	34
 Flash off	13	Beep sound 	34
 Super macro mode	13	BGM	24
 Macro mode	13	BLACK & WHITE	26
 button (print)	14	BRIGHTNESS	27
 button (exposure compensation)	13	C	
 button (self-timer)	13	CALENDAR	26, 27
 button (flash mode)	13	Calendar display	12
 button (macro)	13	Card	33, 77
 button	15	Card access lamp	54, 65, 79
 button (OK/FUNC)	10	CCD	35, 73
 button (erase)	14	Close-up playback 	12

Search by Objective ▶▶▶ Shooting tips and information

 P. 59

5 Getting to know your camera better

Shooting tips and information

Tips before you start taking pictures

The camera does not turn on even when a battery is loaded

The battery is not fully charged

- Charge the battery with the charger.

The battery is temporarily unable to function because of the cold

- Battery performance declines in low temperatures, and the charge may not be sufficient to turn on the camera. Remove the battery and warm it by putting it in your pocket for a while.

















No picture is taken when the shutter button is pressed

Contents

How to use this manual	2
Contents	3

1 Button operations 8







Test out the functions of the camera buttons by following the illustrations and actually trying them out on the camera.






POWER button	Turning the camera on and off	8
Shutter button	Shooting pictures	8
Mode dial	Switching between shooting and playback modes	9
	Shooting still pictures	9
	Shooting pictures using image blur reduction	9
SCN	Shoot pictures by selecting a scene according to the situation	9
GUIDE	Follow the shooting guide for setting	9
	Recording movies	9
	Viewing still pictures/Selecting playback mode	10
Arrow pad (   )		10
 button (OK/FUNC)		10
P/AUTO	Shooting pictures with automatic settings	10
MENU button (MENU)		11
Zoom button	Zooming while shooting/close-up playback	11
 button	Flash shooting	13
 button	Shooting pictures close to the subject	13
 button	Self-timer shooting	13
 button	Changing picture brightness	13
 button	Erasing pictures	14
 button	Printing pictures	14
 button	Changing the information on display/Display the menu guide	15

2 Menu operations 16

Learn everything about the menus, from basic operations to the functions of each menu and their various settings.

About the menus	16
Using the menus	17
Shooting mode menu	19
IMAGE QUALITY	Changing the image quality 19

RESET	Change the shooting functions back to default settings	20
SCN (Scene).....	Shooting pictures by selecting a scene according to the situation	20
CAMERA MENU		21
WB	Adjusting the color of a picture	21
ISO	Changing the ISO sensitivity	21
DRIVE	Continuous shooting	22
ESP/ 	Changing the area for measuring the brightness of a subject	22
DIGITAL ZOOM	Zooming in on your subject	22
AF MODE.....	Changing the focusing area	23
	Recording sound with still pictures	23
PANORAMA	Creating a panoramic picture	23
Playback mode menu		24
SLIDESHOW	Playing back pictures automatically	24
MOVIE PLAY	Playing back movies	25
CALENDAR	Playing back the pictures in a calendar format	26
INDEX.....	Viewing the pictures as a thumbnail	26
EDIT.....		26
	Changing the size of pictures	26
REDEYE FIX.....	Fixing the red-eye in pictures	26
BLACK & WHITE	Changing pictures to black and white	26
SEPIA	Changing pictures to a sepia tone	26
FRAME	Synthesize the frame and the picture	26
TITLE	Synthesize the title and the picture	27
CALENDAR	Synthesize the calendar using the picture	27
BRIGHTNESS.....	Change the brightness of the picture	27
SATURATION.....	Change the vividness of the picture	27
INDEX	Making an index picture from a movie	27
PRINT ORDER	Making print reservations (DPOF)	28
PLAYBACK MENU		28
	Protecting pictures	28
	Rotating pictures	28
	Adding sound to still pictures	28
ALBUM ENTRY	Adding pictures to an album	29
ERASE.....	Erase selected pictures/Erase all pictures	30
SEL. IMAGE.....	Erase by selecting the single-frame	30
ALL ERASE	Erase all the pictures in the internal memory and the card	30
ALBUM	See the pictures registered in the album	30
Album playback menus		31
SEL. ALBUM.....	See other album	31
PLAYBACK MENU		32
UNDO ENTRY	Undoing album entries	32
SELECT JACKET	Selecting the jacket	32

SETUP menus	33
MEMORY FORMAT (FORMAT) Formatting the internal memory or card	33
BACKUP Copying pictures in the internal memory to the card	33
 Selecting a display language	34
PW ON SETUP Setting the startup screen and volume	34
SCREEN SETUP Registering a picture as the startup screen	34
COLOR Setting the color of the menu screens	34
BEEP Adjusting the volume of beep when button is pressed	34
 Adjust the volume of camera warning sound	34
SHUTTER SOUND Selecting the sound of the shutter button	34
VOLUME Adjusting the volume during playback	35
REC VIEW Viewing pictures immediately	35
FILE NAME Resetting the file names of pictures	35
PIXEL MAPPING Adjusting the image processing function	35
 Adjusting the monitor brightness	36
 Setting the date and time	36
DUALTIME Setting the date and time in another time zone	36
ALARM CLOCK Setting alarms	37
VIDEO OUT Playing back pictures on a TV	38
 Display the histogram	38
FRAME ASSIST Display the frame assist/Decide the type	38

3 Printing pictures 39

Learn how to print pictures you have taken.

Direct printing (PictBridge)	40
Using the direct printing function	40
EASY PRINT	40
Other print modes and print settings (CUSTOM PRINT)	42
Print settings (DPOF)	45
How to make print reservations	45
Single-frame reservation	46
All-frame reservation	46
Resetting print reservation data	47

4 Connecting the camera to a computer48

Learn how to transfer pictures to a computer and save them.

Flow	48
Using OLYMPUS Master	48
What is OLYMPUS Master?	48
Install the OLYMPUS Master software	49
Connecting the camera to a computer	52
Start up the OLYMPUS Master software	53
Displaying camera images on a computer	54
Downloading and saving images	54
Viewing still pictures and movies	56
Printing pictures	57
To download and save images to a computer without using OLYMPUS Master ...	58

5 Getting to know your camera better59

Find out more about your camera and learn what to do when you have a question regarding operations.

Shooting tips and information	59
Tips before you start taking pictures	59
The camera does not turn on even when a battery is loaded	59
No picture is taken when the shutter button is pressed	59
The date and time have not been set	60
Shooting tips	60
Focusing on the subject	60
Subjects that are difficult to focus on	61
Taking pictures without blurring	61
Taking pictures without the flash	62
The picture is too grainy	62
Taking pictures with the correct color	62
Taking pictures of a white beach or snow scene	63
Taking pictures of a subject against backlight	63
Additional shooting tips and information	63
Increasing the number of pictures that can be taken	63
Using a new card	64
Lamp indicators	65
Extending the useful life of the battery	65
Functions that cannot be selected from menus	65


Selecting the optimal record mode.....	66
To return the settings of functions to default settings.....	66
Confirming the exposure when the monitor is difficult to see outdoors ...	66
Playback help.....	66
The red-eye cannot be fixed	66
The picture cannot be registered in the album.....	66
Playback tips.....	67
Playing back the picture in the internal memory	67
Understanding the settings and other information of pictures taken .	67
Quickly displaying a desired picture.....	67
Erasing sound recorded to still pictures	67
Viewing pictures on a computer.....	68
Viewing the entire picture on a computer screen	68
When you get an error message on the camera	69
Functions available in shooting modes and scenes	71
Glossary of terms.....	73

6 Miscellaneous 75

Read about convenient functions and safety precautions on how to use your camera more effectively.

Camera care.....	75
Battery and charger	76
Useful use of the accessories.....	77
The card.....	77
AC adapter.....	79
Safety Precautions.....	80
Index.....	83

1 Button operations



1 POWER button

Turning the camera on and off

Power on:

- Shooting mode
- Monitor turns on
- Lens extends

Playback mode


- Monitor turns on

2 Shutter button

Shooting pictures

Shooting still pictures


Set the mode dial to , or **SCN**, and lightly press the shutter button (halfway). The green lamp lights when the focus and exposure are locked (focus lock). Now press the shutter button all the way (fully) to shoot a picture.



Locking the focus and then composing the shot (focus lock)

Compose your picture with the focus locked, and then fully press the shutter button to shoot a picture.

- When the green lamp blinks, the focus and exposure are not adjusted properly. Try locking the focus again.




Locking the focus position (AF lock)

When the scene is or , you can lock the focus position by pressing . Press again to cancel the AF lock.

SCN Shooting pictures by selecting a scene according to the situation" (P. 20)

Recording movies

Set the mode dial to , and lightly press the shutter button to lock the focus, and then press the shutter button fully to start recording. Press the shutter button again to stop recording.

3 Mode dial

Switching between shooting and playback modes

Set the mode dial to the desired shooting or playback mode.

Shooting still pictures

The camera determines the optimum settings and shoots the picture.

Shooting pictures using image blur reduction

This function reduces the blur incurred by a moving subject or camera movement when taking pictures.

- By switching to the other mode, most settings will be changed to the default settings of each mode.


SCN Shoot pictures by selecting a scene according to the situation

You can shoot pictures by selecting a scene according to the situation.

Select the scene/change the scene to another one

- Press the **MENU** button to select [SCN] from the top menu, and change it to another scene.
- By switching to the other scene, most settings will be changed to the default settings of each scene.

GUIDE Follow the shooting guide for setting



Follow the shooting guide displayed on the screen to set the target items.


Recording movies

Audio is recorded with the movie.



This lights red during movie recording.

The remaining recording time is displayed. When the remaining recording time reaches 0, recording stops.



▶ Viewing still pictures/Selecting playback mode

The last picture taken is displayed.

- Press the arrow pad (▲▼◀▶) to view other pictures.
- Use the zoom button to switch among close-up playback, index display and calendar display.

👉 Movie playback “MOVIE PLAY Playing back movies” (P. 25)

4 Arrow pad (▲▼◀▶)

Use the arrow pad to select scenes, playback picture, and the items on the menus.

5 OK/FUNC button (OK/FUNC)

Displays the function menu and sets the functions often used in shooting mode. This button is also used to confirm your selection.

The functions you can set with the function menu

P/AUTO Shooting pictures with automatic settings





Select the shooting mode when you have set the mode dial to 📷.

P (Program auto)	The camera automatically sets the optimum aperture value and shutter speed for the brightness of the subject.
AUTO (Full auto mode)	The camera automatically sets white balance and ISO sensitivity in addition to the aperture and shutter speed.

- 👉 “WB Adjusting the color of a picture” (P. 21)
- “ISO Changing the ISO sensitivity” (P. 21)
- “DRIVE Continuous shooting” (P. 22)
- “ESP/📷 Changing the area for measuring the brightness of a subject” (P. 22)

Function menu



-  : Select the setting items.
-   : Select a setting, and press .

6 MENU button (MENU)

Displays the top menu.


7 Zoom button

Zooming while shooting/close-up playback


Shooting mode: Zooming in on your subject

Optical zoom: 3×

Zoom out:
Press W on the
zoom button.




Zoom in:
Press T on the
zoom button.



Playback mode: Switching the picture display

Single-frame playback

- Use the arrow pad $\triangle \nabla \leftarrow \rightarrow$ to browse pictures.



Index display


- Use the arrow pad ($\triangle \nabla \leftarrow \rightarrow$) to select a picture for playback, and press \odot to play back the single-frame of the picture selected.

Close-up playback

- Press T to incrementally enlarge the picture up to 10 times the original size. Press W to reduce the size.
- Press the arrow pad ($\triangle \nabla \leftarrow \rightarrow$) during close-up playback to scroll the picture in the indicated direction.
- When returning to the single-frame playback, press \odot .



Calendar display




- Use the arrow pad ($\triangle \nabla \leftarrow \rightarrow$) to select the date, and press \odot or T of the zoom button to display the picture on the date selected.





SUN	MON	TUE	WED	THU	FRI	SAT
2008	26	27	28	1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	1
2	3	4	5	6	7	8



8  **button****Flash shooting**

Press the  button in shooting mode to select the flash mode.
Press  for setting.



AUTO (Auto-flash)	The flash fires automatically in low light or backlight conditions.
 Red-eye reduction flash	This emits pre-flashes for red-eye reduction.
 Fill-in flash	The flash fires regardless of the available light.
 Flash off	The flash does not fire even in low light conditions.



9  **button****Shooting pictures close to the subject**


Press the  button in shooting mode to select the macro mode.
Press  for setting.


 Macro mode	This mode lets you shoot from as close as 20cm/7.8 in. (when the zoom is set for the zoom-out angle) and as close as 50cm/19.6 in. (when the zoom is set for the zoom-in angle) to your subject.
 Super macro mode	This mode lets you shoot from as close as 8cm/3.1 in. to your subject.


10  **button****Self-timer shooting**

Press the  button in shooting mode to select on and off of the self-timer.
Press  for setting.

 ON	After the setting, press the shutter button fully.
 OFF	Cancel the self-timer.

- The self-timer lamp lights for approximately 10 seconds, blinks for approximately 2 seconds, and then the picture is taken.
- To cancel the self-timer, press the .
- Self-timer shooting is automatically canceled after one shot.


11  **button****Changing picture brightness**




Press the  button in shooting mode to adjust the exposure.

- Adjustable from - 2.0EV to +2.0 EV



Activate the setting contents.

- : Brighten
- : Darken

**12**  **button****Erasing pictures**



- In playback mode, select the picture you want to erase, and press the  button.
- Once erased, pictures cannot be restored. Check each picture before erasing to avoid accidentally erasing pictures you want to keep.
-  “ Protecting pictures” (P. 28)

13  **button****Printing pictures**

- Display a picture to print out in playback mode, and press the  button.
-  “EASY PRINT” (P. 40)

Changing the information displays

Press the **DISP** button to change the display in the following order.

Shooting mode**Playback mode**

*¹ Not displayed in case of .

*² Not displayed when the mode is set [OFF] in the menu.


“ Display the histogram” (P. 38)

“FRAME ASSIST Display the frame assist/Decide the type” (P. 38)

Displaying the menu guide

With menu items selected, hold down the **DISP** button to display the menu guide. Release the **DISP** button to close the menu guide.

2 Menu operations




About the menus

Press the **MENU** button to display the top menu.


The contents displayed on the top menu differ according to the mode.

- When the mode dial is set at **GUIDE**, press the **MENU** button to display the shooting guide screen.

Top menu in the shooting mode




- When [CAMERA MENU], [PLAYBACK MENU], [EDIT], [ERASE], or [SETUP] is selected, the screen for selecting the menu item is displayed in addition.



When [CAMERA MENU] is selected

Top menu in the playback mode



When [PLAYBACK MENU] is selected

Using the menus

Use the arrow pad ($\triangle \nabla \triangleleft \triangleright$) and OK/FUNC to set menu items.

This explains how to use the menus with the [AF MODE] setting as an example.

Set the mode dial to the desired mode.

- In this case, set the mode dial to P .



1 Press the MENU button to display the top menu, and then press OK/FUNC .

- [AF MODE] is on a menu in [CAMERA MENU]. Press OK/FUNC .
- To display other menus, use the arrow pad ($\triangle \nabla \triangleleft \triangleright$) to select a menu, and press OK/FUNC .
- To close the top menu, press the MENU button.



2 Press $\triangle \nabla$ to select a setting, and press OK/FUNC .

- [AF MODE] is the sixth menu item, so press ∇ five times, and then press OK/FUNC .
- Unavailable settings cannot be selected.


Top menu




This mark is displayed when there are more menu items on the next page.





The selected item is displayed in a different color.





3 Press \triangle / ∇ to select a setting, and press OK .

- Select the [AF MODE] from [I]ESP and [SPOT] and then press OK .
- The menu item is set and the previous menu is displayed.



When there are more menu items on the next page, press \triangleleft on the procedure 2 screen to move the cursor to the page display. Press \triangle / ∇ to change the page.

To return to the previous page, press \triangleright or OK .



*2 [RESET] cannot be selected when the mode dial is set to **SCN** ().

*3 **SCN** can be selected when the mode dial is set to **SCN**.

“SETUP menus” (P. 33)

• Some functions are not available according to the selected mode.

“Functions available in shooting modes and scenes” (P. 71)

• The factory default settings are displayed in gray ().

1 IMAGE QUALITY

Changing the image quality

Still picture image quality and their applications

Image quality/Image size	Compression	Application
SHQ 3072 × 2304	Low compression	• This is useful for printing large images on full-size paper.
HQ 3072 × 2304	Standard compression	• This is useful for performing computer image processing, such as contrast adjustment and red-eye correction.
SQ1 2560 × 1920 2304 × 1728 2048 × 1536	Standard compression	• This is useful for postcard-sized prints. • This is useful for computer editing such as rotating or adding text to a picture.
SQ2 1600 × 1200 1280 × 960 1024 × 768 640 × 480	Standard compression Low compression	• This is useful for viewing pictures on a computer. • This is useful for sending as e-mail attachments.

Movie image quality

Image quality/Image size
SHQ 640 × 480
HQ 320 × 240
SQ 160 × 120

2 RESET Change the shooting functions back to default settings

NO /YES

Restore shooting functions back to default settings. The mode dial has to be set to (P or AUTO) in order to restore default settings.

Functions for returning the settings to the original when the reset function is executed

Function	Factory default setting	Ref. Page
Flash	AUTO	P. 13
	OFF	P. 13
	0.0	P. 13
IMAGE QUALITY	HQ	P. 19
	OFF	P. 13
WB	AUTO	P. 21
ISO	AUTO	P. 21
DRIVE	<input type="checkbox"/>	P. 22
ESP/	ESP	P. 22
DIGITAL ZOOM	OFF	P. 22
AF MODE	SPOT	P. 23
	OFF	P. 23

3 SCN (Scene) Shooting pictures by selecting a scene according to the situation

The scene selection screen displays sample images and the shooting mode to best suit the situation.

- By switching to the other scene, most settings will be changed to the default settings of each scene.


Scene selection



Press to decide the scene.

[Shoot & Select1] / [Shoot & Select2]

- Press and hold the shutter button to shoot pictures. After shooting pictures, select the ones you want to erase, put the ✓ to them, and press button to erase them.



4 CAMERA MENU




WB Adjusting the color of a picture

AUTO		The white balance is adjusted automatically for natural color, regardless of the light source.
	Sunny day	For shooting under a clear sky.
	Cloudy day	For shooting under a cloudy sky.
	Tungsten light	For shooting under tungsten lighting.
	Fluorescent lamp 1	For shooting under daylight fluorescent lighting. (This type of lamp is mainly used in homes.)
	Fluorescent lamp 2	For shooting under a neutral white fluorescent lamp. (This type of lamp is mainly used in desk lamps.)
	Fluorescent lamp 3	For shooting under a white fluorescent lamp. (This type of lamp is mainly used in offices.)

ISO Changing the ISO sensitivity

AUTO	Sensitivity is automatically adjusted according to the conditions of the subject.
64/100/200/ 400/800/ 1600	A low value lowers the sensitivity for daylight shooting of clear, sharp pictures. The higher the value, the better the camera's light sensitivity and ability to shoot with a fast shutter speed and in low light conditions. However, high sensitivity introduces noise into the resulting picture, which may give it a grainy appearance.



DRIVE..... **Continuous shooting**

	Shoots 1 frame at a time when the shutter button is pressed.
	Focus, exposure and white balance are locked at the first frame. The sequential shooting speed varies depending on the record mode setting.
	Pictures can be taken at a faster speed than normal sequential shooting.

You can take a sequence of pictures at one time while holding down the shutter button. The camera will take pictures in sequence until you release the shutter button.

- In speed sequential shooting, [IMAGE QUALITY] will be limited to below [2048 × 1536].


ESP/ **Changing the area for measuring the brightness of a subject**

	Meters the brightness at the center of the monitor and the surrounding area separately to create a picture with balanced brightness. When taking pictures against strong backlight, the center of the picture may appear dark.
	Only the center of the monitor is metered. Suitable for taking a picture of the subject in the center of the monitor against backlight.

DIGITAL ZOOM..... **Zooming in on your subject**

OFF /ON

The digital zoom can be used to take close-up shots with stronger magnification when combined with optical zoom. (Optical Zoom x Digital Zoom : the maximum 15x)



Zoom bar
 White area: The optical zoom area
 Red area: The digital zoom area

AF MODE Changing the focusing area

iESP	The camera determines which subject within the screen to focus on. Even when the subject is not in the center of the screen, focusing is possible.
SPOT	Focus selection is based on the subject within the AF target mark.

..... Recording sound with still pictures


OFF / ON

Recording starts about 0.5 seconds after the shutter button is released and lasts about 4 seconds.


When recording, aim the camera microphone at the source of the sound you want to record.

PANORAMA Creating a panoramic picture



Panorama shooting lets you create a panoramic picture, using the OLYMPUS Master software from the provided CD-ROM. An Olympus xD-Picture Card is required for panorama shooting.









Connects pictures from left to right




Connects pictures from bottom to top

- : The next picture is connected at the right edge.
- : The next picture is connected at the left edge.

- : The next picture is connected at the top.
- : The next picture is connected at the bottom.


Use the arrow pad () to specify at which edge you want to connect the pictures, and then compose your shots so that the edges of the pictures overlap. The part of the previous picture where it will be joined to the next picture does not remain in the frame. You have to remember what the part in the frame looked like and take the next picture so it overlaps.




Panorama shooting is possible for up to 10 pictures. Press **MENU** button to exit panorama shooting.



When a still picture is selected



When the movie is selected




*1 A card is required.

👉 “SETUP menus” (P. 33)

- The factory default settings are displayed in gray ().

1 SLIDESHOW

Playing back pictures automatically



- Set [BGM] to [ON] or [OFF].
- Select the transition effect between pictures from [TYPE].

BGM	ON	/ OFF
TYPE	NORMAL	
	FADER	
	SLIDE	
	ZOOM	

- Only the first frame of each movie is displayed.
- After setting [BGM] and [TYPE], press **OK** to start the slideshow.
- Press **ESC** or **MENU** button to cancel the slideshow.

Select [MOVIE PLAY] from the top menu, and press to play back the movie. Another option is to select a picture with the movie icon (), and press to play back the movie.



Operations during movie playback



Playing time/Total recording time

: Increases the volume.

: Reduces the volume.

: Each time you press the button, the playback speed changes in the following order: 2x; 20x; and back to 1x.

: Plays the movie in reverse. Each time you press the button, the playback speed changes in the following order: 2x; 20x; and back to 1x.

- Press to pause the playback.

Operations during pause



: Displays the first frame.

: Displays the last frame.

: Displays the next frame.

: Displays the previous frame.

- To resume the movie, press .
- To cancel the playback of the movie in the middle of it or during pause, press the **MENU** button.

3 CALENDAR**Playing back the pictures in a calendar format**

This function lets you play back the pictures in a calendar format by the date of recording.

“Zoom button Zooming while shooting/close-up playback” (P. 11)

4 INDEX**Viewing the pictures as a thumbnail**

This function lets you view the pictures in 9 frames at the same time.

“Zoom button Zooming while shooting/close-up playback” (P. 11)

5 EDIT

This function lets you edit still pictures saved on a card and store them as new pictures.

..... **Changing the size of pictures**

640 × 480 / 320 × 240

This changes the image size of a picture and saves it as a new file.

REDEYE FIX.....**Fixing the red-eye in pictures**

This function corrects the red-eye look that often occurs when taking pictures with a flash.

BLACK & WHITE.....**Changing pictures to black and white**

This changes the picture to black and white and saves it as a new file.

SEPIA**Changing pictures to a sepia tone**

This changes the picture to sepia and saves it as a new file.

FRAME.....**Synthesize the frame and the picture**

This function lets you select the frame, and synthesize the frame and the picture, and store it as a new picture.



- Select a frame with and press .
- Select the picture to be synthesized with the frame with , and press . Press to turn the picture 90 degrees clockwise or 90 degrees counterclockwise.
- Press the arrow pad () or zoom button, adjust the position and size of the picture, and press .

TITLE **Synthesize the title and the picture**


This function lets you select the title, synthesize the title and the picture, and store it as a new picture.



- Select the picture with \triangleleft , and press OK (FUNC).
- Select the title with \triangleleft , and press OK (FUNC). Press \triangle / ∇ to turn the title 90 degrees clockwise and 90 degrees counterclockwise.
- Press the arrow pad (\triangle / ∇ / \triangleleft) or zoom button, adjust the position and size of the title, and press OK (FUNC).
- Set the color of the title with the arrow pad (\triangle / ∇ / \triangleleft), and press OK (FUNC).

CALENDAR **Synthesize the calendar using the picture**


This function lets you select the calendar, synthesize the calendar and the picture, and store it as a new picture.



- Select the picture with \triangleleft , and press OK (FUNC).
- Select the calendar with \triangleleft , and press OK (FUNC). Press \triangle / ∇ to turn the picture 90 degrees clockwise and 90 degrees counterclockwise.
- Set the date of the calendar, and press OK (FUNC).

BRIGHTNESS **Change the brightness of the picture**


This function lets you adjust the brightness of the picture, and store it as a new picture.



- Select the picture with \triangleleft , and press OK (FUNC).
- Adjust the brightness with \triangle / ∇ , and press OK (FUNC).

SATURATION **Change the vividness of the picture**

This function lets you adjust the vividness of the picture, and store it as a new picture.



- Select the picture with \triangleleft , and press OK (FUNC).
- Adjust the vividness with \triangle / ∇ , and press OK (FUNC).

INDEX **Making an index picture from a movie**

This extract 9 frames from a movie and saves them as a new picture (INDEX).

6 PRINT ORDER

Making print reservations (DPOF)

This function allows you to save printing data (the number of prints and the date and time information) with the pictures stored on the card.

🔑 “Print settings (DPOF)” (P. 45)

7 PLAYBACK MENU

🔑 Protecting pictures

OFF / ON




Protected pictures cannot be erased, but they are all erased by formatting.

- Select the picture with $\leftarrow \rightarrow$, and protect it by selecting [ON] with $\triangle \nabla$. You can protect several frames in succession.

📁 Rotating pictures

+90° / 0° / -90°

Pictures taken with the camera held vertically are displayed horizontally. This function lets you turn such pictures so that they are displayed vertically. New picture orientations are saved even when the power is turned off.



+90°




0°



-90°

🎤 Adding sound to still pictures



Sound is recorded for about 4 seconds.


- When [START] is displayed, aim the camera microphone at the source of the sound you want to record, and press PHOTO .
- Recording starts and the [BUSY] bar is displayed during recording.

ALBUM ENTRY Adding pictures to an album


Pictures recorded to the card can be organized by sorting them into albums. Pictures stored in the internal memory cannot be entered in albums.

☞ “Album playback menus” (P. 31)

Select the album entry method



Select an album to add the pictures




[SEL. IMAGE]



[SET CALENDAR]



[SET ALL]



Select one frame at a time for entry

- Press the arrow pad ($\triangle \nabla \leftarrow \rightarrow$) to select a picture, and press $\text{OK} \text{ FRC}$ to add \checkmark .
- Press $\text{OK} \text{ FRC}$ again to cancel the selection.
- When the selection is completed, press $\text{OK} \text{ FRC}$ for a while.

Add pictures taken on the same day

Use the arrow pad ($\triangle \nabla \leftarrow \rightarrow$) to select the date with pictures to enter in the album, and press $\text{OK} \text{ FRC}$.

Select all images Select all still images, all protected images, or all movies.

8 ERASE**Erase selected pictures/Erase all pictures**

Protected pictures cannot be erased. Cancel protection before erasing such pictures. Once erased, pictures cannot be restored. Check each picture before erasing to avoid accidentally erasing pictures you want to keep.

- When erasing the picture in the internal memory, do not insert the card into the camera.
- When erasing the picture from the card, insert a card into the camera in advance.

SEL. IMAGE Erase by selecting the single-frame


- Use the arrow pad ($\triangle \nabla \triangleleft \triangleright$) to select the picture, and press DISP to put \checkmark .
- To cancel the selection, press DISP again.
- When the selection is completed, press DISP button.
- Select [YES], and press DISP .

ALL ERASE.....Erase all the pictures in the internal memory and the card


- Select [YES], and press DISP .

9 ALBUM**See the pictures registered in the album**

Use the arrow pad ($\triangle \nabla \triangleleft \triangleright$) to select an album, and press DISP .




Use the arrow pad ($\triangle \nabla \triangleleft \triangleright$) to display picture you want.




Album playback menus

- A card is required.

When the still picture is selected



When the move is selected



- *1 This is not displayed when the movie is selected.
- *2 The still pictures registered in the album cannot be recorded.

- ☞ “SLIDESHOW Playing back pictures automatically” (P. 24)
- ☞ “MOVIE PLAY Playing back movies” (P. 25)
- ☞ “Print settings (DPOF)” (P. 45)
- ☞ “SETUP menus” (P. 33)
- ☞ “ERASE Erase selected pictures/Erase all pictures (P. 30)

1 SEL. ALBUM

See other album

To switch albums, select the desired album from [SEL. ALBUM].

- ☞ “ALBUM See the pictures registered in the album” (P. 30)

2 PLAYBACK MENU

UNDO ENTRY.....Undoing album entries

Even if a picture is removed from an album, the picture remains in the card.

SEL. IMAGE

Select one frame at a time to undo.



- Press the arrow pad (△▽◀▶) to select a picture, and press to add ✓.
- Press again to cancel the selection.
- When the selection is completed, press for a while.

UNDO ALL

Undo all pictures in the album

SELECT JACKET.....Selecting the jacket




You can change the jacket (first frame in the album) to be displayed on the album selection screen.


Title image (first frame in the album)

Other album menus

“ Protecting pictures” (P. 28)

“ Rotating pictures” (P. 28)



- *1 A card is required.
- *2 [SCREEN SETUP] can be selected when playing back still pictures.
- *3 You cannot make the selection in shooting mode.
- *4 You cannot select this item when the mode dial is set to .
- *5 You cannot select this item in playback mode.

MEMORY FORMAT (FORMAT)..... Formatting the internal memory or card

All existing data, including protected pictures, are erased when the internal memory or card is formatted. Make sure that you save or transfer important data to a computer before formatting the card.

- Make sure there is no card inserted in the camera when formatting the internal memory.
- When the internal memory is formatted, the data of the frames and titles downloaded with the provided OLYMPUS Master software will be deleted.
- Be sure that the card is inserted in the camera when formatting the card.
- Before using non-Olympus cards or cards which have been formatted on a computer, you must format them with this camera.

BACKUP Copying pictures in the internal memory to the card

Insert the optional card into the camera. Copying data does not erase the picture in the internal memory.

- It takes some time to back up data. Check if the battery is not empty before starting the copy, or use the AC adapter.

..... Selecting a display language

You can select a language for on-screen display. Available languages vary depending on the area where you purchased this camera.

You can add other languages to your camera with the provided OLYMPUS Master software.

PW ON SETUP Setting the startup screen and volume

SCREEN OFF (No picture is displayed.) / 1 / 2 (The picture registered with [SCREEN SETUP] is displayed.)

VOLUME OFF (No sound) / LOW / HIGH

You can select the volume level and the picture displayed when the camera is turned on. If [SCREEN] is set to [OFF], [VOLUME] cannot be set.

SCREEN SETUP Registering a picture as the startup screen

Still pictures in the internal memory or the card can be registered to screen [2] for [PW ON SETUP].

If a picture is already registered, the [IMAGE EXISTING] screen is displayed asking if you want to cancel the currently registered picture and register a new one.

COLOR Setting the color of the menu screens

NORMAL /BLUE /BLACK / PINK

BEEP Adjust the volume of operation sound when the button is pressed

OFF (No sound) / LOW / HIGH

■)) Adjust the volume of camera warning sound

OFF (No sound) / LOW / HIGH

SHUTTER SOUND Selecting the sound of the shutter button

OFF (No sound) /

1 LOW / HIGH

2 LOW / HIGH

3 LOW / HIGH

VOLUME **Adjusting the volume during playback**

OFF (No sound) / **LOW** / HIGH

REC VIEW **Viewing pictures immediately**

OFF The picture being recorded is not displayed. This is useful when you want to prepare for your next shot while the previous picture is being recorded.


ON The picture being recorded is displayed. This is useful for making a brief check of the picture you have just taken. You can resume shooting while the picture is still being displayed.


FILE NAME **Resetting the file names of pictures**

RESET This method is useful when grouping files on separate cards. The file number and folder number are reset every time a new card is inserted in the camera. The folder number returns to [No. 100] and the file number returns to [No. 0001].


AUTO This method is useful when you want to manage all your files with sequential numbers. Even if a new card is inserted, the folder number and file number are retained from the previous card. This helps you to manage multiple cards.

File names and their folder names for recorded pictures are automatically generated by the camera. File names and folder names respectively include file numbers (0001 to 9999) and folder names (100 to 999), and are named as follows.

**PIXEL MAPPING** **Adjusting the image processing function**

The pixel mapping feature allows the camera to check and adjust the CCD and image processing functions. It is not necessary to operate this function frequently. Approximately once a year is recommended. Wait at least one minute after taking or viewing pictures to allow the pixel mapping function to perform properly. If you turn the camera off during pixel mapping, start again. Select [PIXEL MAPPING]. When [START] is displayed, press .

..... Adjusting the monitor brightness





2

Menu operations


..... Setting the date and time


The date and time is saved with each image, and is used in the file name.





- The first two digits of the year are fixed.
- The time is displayed in the 24-hour format.
- For a more accurate setting, press  when the time signal hits 00 seconds.

DUALTIME Setting the date and time in another time zone

OFF	Switches to the date and time set in  .
ON	Switches to the date and time set in [DUALTIME]. When setting the dual time, select [ON], and then set the time.




- The date format is the same as that set with .
- The first two digits of the year are fixed.
- The time is displayed in the 24-hour format.
- For a more accurate setting, press  when the time signal hits 00 seconds.

ALARM CLOCKSetting alarms

OFF	No alarm is set or alarm is canceled.
ONE TIME	Alarm is activated once.
DAILY	Alarm is activated daily at the set time.

- When [⏪] has not been set, [ALARM CLOCK] is not available.
- When [DUALTIME] is set to [ON], the alarm sounds according to the dual time date and time setting.

Setting an alarm



- Select [ONE TIME] or [DAILY], and set the alarm time.
- You can set snooze (alarm intervals) or alarm sounds and volume.

TIME	Sets the alarm time.	
SNOOZE	OFF	No snooze is set.
	ON	Alarm is activated every 5 minutes, up to 7 times.
ALARM SOUND	1	LOW / MID / HIGH
	2	LOW / MID / HIGH
	3	LOW / MID / HIGH

Operating, shutting off and checking the alarm

- Operating the alarm:
Turn off the camera. The alarm only operates when the camera is off.
- Shutting off the alarm:
While the alarm is sounding, press any button to shut off the alarm and turn off the camera. Note that pressing the **POWER** button will turn the camera on. When [SNOOZE] is set to [ON] at this time, the setting will be canceled. When [SNOOZE] is [OFF], the alarm stops automatically and the camera turns off after 1 minute of no operation.
- Checking the alarm settings:
While the camera is off, press the $\frac{\text{DISP.}}{\text{⏻}}$ button to display the set alarm time and the current time for 3 seconds.

VIDEO OUTPlaying back pictures on a TV

NTSC / PAL

The factory default settings differ according to the region where the camera is sold.

To play back camera images on a TV, set the video output according to your TV's video signal type.


- TV video signal types by country/region Check the video signal type before connecting the camera to the TV.


NTSC: North America, Taiwan, Korea, Japan





PAL: European countries, China

Playing back pictures on a TV

Turn off the camera and the TV before connecting.

**Settings on the camera**

Set the mode dial to , and press the **POWER** button to turn the camera on.

- The last picture taken is displayed on the TV. Use the arrow pad (, , , ) to select the picture you want to display.


Settings on the TV


Turn the TV on, and set it to video input mode.


- For details of switching to video input, refer to your TV's instruction manual.

**Display the histogram**

OFF / ON

Set the display or nondisplay of the histogram when  button is pressed in shooting mode.

FRAME ASSISTDisplay the frame assist/Decide the typeOFF /  / 

Set the display or nondisplay and the type of frame assist to be displayed when  button is pressed in shooting mode.


3 Printing pictures

You can print out the pictures you have taken.

If you print the pictures at home, you can either connect the camera directly to the printer or you can connect the camera to a computer and download the pictures to the computer first.

If you go to a photo store, it is a good idea to store the print reservation data on the card first. With print reservation, you can print out pictures easily either at home using a personal DPOF-compatible printer or at a photo store that supports DPOF. DPOF is a standard format used to record automatic print information from digital cameras. It allows you to store data such as which pictures you want to print and the number of prints so that you can print pictures automatically at home or at a photo store.

This chapter explains direct printing and print reservations.



Direct printing (PictBridge)

Using the direct printing function

By connecting the camera to a PictBridge-compatible printer, you can print out pictures directly. Select the pictures you want to print and the number of prints on the camera's monitor.

To find out if your printer is compatible with PictBridge, refer to the printer's instruction manual.

What is PictBridge?

A standard for connecting digital cameras and printers of different makers and printing out pictures directly.

- Available printing modes, paper sizes etc., vary depending on the printer you use. Refer to the instruction manual for your printer.
- For details of printing paper types, ink cassettes, etc., refer to the printer's instruction manual.


EASY PRINT

[EASY PRINT] can be used to print out the picture displayed on the monitor. The selected picture is printed using the standard settings of your printer. The date and file name are not printed.

STANDARD

All printers that support PictBridge have standard print settings. If [STANDARD] is selected on the settings screens (P.42 to 43), pictures are printed according to these settings. Refer to the printer's instruction manual for its standard settings or contact the printer manufacturer.



- 1 Display the picture you want to print out on the LCD monitor in the playback mode.**
- 2 Turn the printer on and plug the USB cable provided with the camera into the multi-connector of the camera and the printer's USB port.**



- The [EASY PRINT START] screen is displayed.
- For details of how to turn the printer on and the position of the USB port, refer to the printer's instruction manual.





3 Press button.

- Printing starts.


- When printing is finished, the picture selection screen is displayed. To print another picture, press  to select a picture, and press  button.
- When you are finished, disconnect the USB cable from the camera with the picture selection screen displayed.

4 Remove the USB cable from the camera.


5 Remove the USB cable from the printer.





You can use [EASY PRINT] even when the camera is turned off or in shooting mode. With the camera turned off or in shooting mode, connect the USB cable. The selection screen for the USB connection is displayed. Select [EASY PRINT].


 "EASY PRINT" Step 3 (P. 41), "CUSTOM PRINT" Step 2 (P. 42)

Other print modes and print settings (CUSTOM PRINT)

1 Display the screen being indicated on the right according to the procedure 1 and 2 in P. 40, and press .




2 Select [CUSTOM PRINT], and press .



Operation guide


3 Make the print settings according to the operation guide.

Selecting the picture to print (available only when a card is inserted)




ALL IMAGES	Allows you to select from all pictures in the card to print.
ALBUM	Select an album and the pictures in the album to print.


Selecting a print mode



PRINT	Prints the selected picture.
ALL PRINT	Prints all the pictures stored in the internal memory or the card.
MULTI PRINT	Prints one picture in multiple layout format.
ALL INDEX	Prints an index of all the pictures stored in the internal memory or the card.
PRINT ORDER	Prints the pictures according to the print reservation data on the card. If no print reservations have been made, this option is not available.

 "Print settings (DPOF)" (P. 45)

Setting the print paper



SIZE	Choose from the available paper sizes on your printer.
BORDERLESS	Select framed or unframed. In [MULTI PRINT] mode, you cannot select the frame.
OFF (<input type="checkbox"/>)	The picture is printed inside a blank frame.
ON (<input type="checkbox"/>)	The picture is printed filling the entire page.
PICS/SHEET	Available in [MULTI PRINT] mode only. The number of prints that can be printed vary depending on the printer.

Note

- If the [PRINTPAPER] screen is not displayed, [SIZE], [BORDERLESS] and [PICS/SHEET] are set to [STANDARD].


Selecting the picture to print



PRINT	Prints one copy of the selected picture. When [SINGLE PRINT] or [MORE] has been selected, a single copy or more copies are printed.
SINGLE PRINT	Makes a print reservation for the displayed picture.
MORE	Sets the number of prints and data to be printed for the displayed picture.

Press to select the picture you want to print. You can also use the zoom button and select a picture from the index display.


Setting the number of prints and data to be printed




x	Sets the number of prints. You can select up to 10 prints.
DATE ()	If you select [WITH], pictures are printed with the date.
FILE NAME ()	If you select [WITH], pictures are printed with the file name.

4 Select [OK], and press

- Printing starts.
- When printing is finished, the [PRINT MODE SELECT] screen is displayed.




To cancel printing




5 In the [PRINT MODE SELECT] screen, press MENU button.

- A message is displayed.




6 Disconnect the USB cable from the camera.

- The camera turns off.



7 Disconnect the USB cable from the printer.



Print settings (DPOF)

How to make print reservations

Print reservation allows you to save printing data (the number of prints and the date and time information) with the pictures stored on the card.

Only the images stored on the card can be reserved to print. Insert a card with recorded pictures into the camera before making print reservations.

Pictures with print reservations can be printed using the following procedures.

Printing using a DPOF-compatible photo store.

You can print the pictures using the print reservation data.


Printing using a DPOF-compatible printer.

Printing is possible directly from a card containing print reservation data, without using a computer. For more details, refer to the printer's instruction manual. A PC card adapter may also be necessary.

Note

- DPOF reservations set by another device cannot be changed by this camera. Make changes using the original device. If a card contains DPOF reservations set by another device, entering reservations using this camera may overwrite the previous reservations.
- Not all functions may be available on all printers, or at all photo stores.

To use print services without using DPOF

- Pictures stored in the internal memory cannot be printed at a photo store. The pictures need to be copied to a card before taking them.
 “BACKUP Copying pictures in the internal memory to the card” (P. 33)

Single-frame reservation


Follow the operation guide to make a print reservation for a selected picture.



1 Press the MENU button in the playback mode and display the top menu.


2 Select [PRINT ORDER] ▶ [FALL], and press .


- Playing back the album: Top menu ▶ [PRINT ORDER] ▶ [FALL]

Operation guide



3 Press  to select the frames for print reservations, and then press  to set the number of prints.

- You cannot make print reservations for pictures with .
- Repeat Step 3 to make print reservations for other pictures.



4 When you finish making print reservations, press .


- The single-frame reservation menu screen is displayed.


5 Select the date and time print setting, and press .


NO The pictures are printed without the date and time.

DATE The selected pictures are printed with the shooting date.

TIME The selected pictures are printed with the shooting time.



6 Select [SET], and press .



All-frame reservation

Reserves all the pictures stored on the card. The number of prints is set at one print per picture.

1 Press the MENU button in the playback mode and display the top menu.

2 Select [PRINT ORDER] ▶ [FALL], and press .


- Playing back the album: Top menu ▶ [PRINT ORDER] ▶ [FALL]

3 Select the date and time setting, and press .

NO The pictures are printed without the date and time.

DATE All pictures are printed with the shooting date.

TIME All pictures are printed with the shooting time.

4 Select [SET], and press .




Resetting print reservation data

You can reset all the print reservation data or just for selected pictures.


1 Select top menu ▶ [PRINT ORDER], and press .

• Playing back the album: Top menu ▶ [PRINT ORDER]



To reset the print reservation data for all the pictures

2 Select  **or**  **], and press** .



3 Select [RESET], and press .



To reset the print reservation data for a selected picture

2 Select  **], and press** .

3 Select [KEEP], and press .


4 Press   **to select the picture with the print reservations you want to cancel, and press**  **to decrease the number of prints to 0.**

• Repeat Step 3 to cancel print reservations for other pictures.

5 When you are finished canceling print reservations, press .

6 Select the date and time setting, and press .

• The setting is applied to the remaining pictures with print reservations.

7 Select [SET], and press .

4 Connecting the camera to a computer

Flow

Using the USB cable provided with your camera, you can connect the camera and computer and download (transfer) the images to your computer using the OLYMPUS Master software, also provided with the camera.

Prepare the following items before starting.



OLYMPUS Master CD-ROM



USB cable



Computer equipped with a USB port

Install the OLYMPUS Master software P. 49

Connect the camera to the computer using the USB cable P. 52

Start up the OLYMPUS Master software P. 53

Download image files to the computer P. 54


Disconnect the camera from the computer P. 54

Using OLYMPUS Master

What is OLYMPUS Master?

OLYMPUS Master is application software for editing images taken with a digital camera on a computer. Installing it on your computer lets you do the following:

- **Download images from the camera or other media**
- **View images and movies**
You can run a slideshow and play back sound.
- **Manage images**
You can organize your images using the calendar display. Search the image you want by date or keyword.
- **Edit images**
You can rotate images, trim them and change the size.
- **Edit images with the filter and correction functions**



- **Print images**
You can print images and make indexes, calendars and postcards.
- **Make panoramic images**
You can make panoramic images using pictures taken in panorama mode.

For details of other functions and operations, refer to the "Help" guide and OLYMPUS Master reference manual.

Install the OLYMPUS Master software

Before installing the OLYMPUS Master software, please confirm that your computer is compatible with the following system requirements.

For newer operating systems, please refer to the Olympus web site as shown on the back cover of this manual.

Operating environment

Windows

OS	Windows 98SE/Me/2000 Professional/XP
CPU	Pentium III 500 MHz or later
RAM	128 MB or more (at least 256 MB is recommended)
Hard disk capacity	300 MB or more
Connector	USB port
Monitor	1,024 × 768 pixels, 65,536 colors or more



Note

- Data transfer is only guaranteed on computers with a factory installed OS.
- To install the software in Windows 2000 Professional/XP, you must log on as a user with administrators' privileges.
- Internet Explorer and QuickTime 6 or later should be installed on your computer.
- Windows XP corresponds to Windows XP Professional/Home Edition.
- Windows 2000 corresponds to Windows 2000 Professional.
- If you are using Windows 98SE, the USB driver is installed automatically.

Macintosh

OS	Mac OS X 10.2 or later
CPU	Power PC G3 500 MHz or later
RAM	128 MB or more (at least 256 MB is recommended)
Hard disk capacity	300 MB or more
Connector	USB port
Monitor	1,024 × 768 pixels, 32,000 colors or more



Note

- Operation is only guaranteed on a Macintosh equipped with a built-in USB port.
- QuickTime 6 or later and Safari 1.0 or later must be installed.
- Be sure to remove the media (drag & drop onto the trash icon) before performing the following operations. Failure to do so could result in unstable computer operation and the need to reboot.
 - Disconnect the cable connecting the camera to the computer
 - Turn off the camera
 - Open the camera's battery compartment/card cover

Windows


1 Insert the CD-ROM into the CD-ROM drive.

- The OLYMPUS Master setup screen is displayed.
- If the screen is not displayed, double-click the “My Computer” icon and click the CD-ROM icon.




2 Click “OLYMPUS Master”.

- The QuickTime installation screen is displayed.
- QuickTime is required to use OLYMPUS Master. If the QuickTime screen is not displayed, QuickTime 6 or later is already installed on the computer. In this case, go to step 4.




3 Click “Next” and follow the on-screen instructions.

- When the QuickTime licensing agreement is displayed, read the agreement and click “Agree” to proceed with the installation.
- The OLYMPUS Master installation screen is displayed.




4 Follow the on-screen instructions.

- When the OLYMPUS Master licensing agreement is displayed, read the agreement and click “Yes” to proceed with the installation.



- When the “User Information” dialog box is displayed, enter your “Name” and “OLYMPUS Master Serial Number”; select your region and click “Next”. Refer to the sticker on the CD-ROM package for the serial number.
- When the DirectX licensing agreement is displayed, read the agreement and click “Yes”.




- A screen asking whether or not you want to install Adobe Reader is displayed. Adobe Reader is required to read the OLYMPUS Master instruction manual. If this screen is not displayed, Adobe Reader is already installed on your computer. To install Adobe Reader, click “OK”.

5 Follow the on-screen instructions.

- The screen confirming that installation is completed is displayed. Click “Finish”.

6 Select the option to restart immediately when the screen asking you if you wish to restart the computer is displayed and click “OK”.

- The computer restarts.
- Remove the CD-ROM from the CD-ROM drive and store it.



Macintosh

1 Insert the CD-ROM into the CD-ROM drive.

- The CD-ROM window is displayed.
- If the CD-ROM window is not displayed, double-click the CD-ROM icon on the desktop.



2 Double-click on the desired language folder.

3 Double-click the “Installer” icon.

- The OLYMPUS Master installer starts up.
- Follow the on-screen instructions.
- When the OLYMPUS Master licensing agreement is displayed, read the agreement and click “Continue” and then “Agree” to proceed with the installation.
- The screen confirming that installation is completed is displayed.



4 Click “Finish”.

- The first screen is displayed.


5 Click “Restart”.

- The computer restarts.
- Remove the CD-ROM from the CD-ROM drive and store it.

Connecting the camera to a computer

1 Make sure the camera is turned off.


- The monitor is off.
- The lens is retracted.



2 Connect the multi-connector on the camera to the USB port on the computer using the provided USB cable.

- Refer to your computer's instruction manual to locate the position of the USB port.
- The camera turns on automatically.
- The monitor turns on and the selection screen for the USB connection is displayed.

Connector cover



Multi-connector

3 Select [PC], and press .


4 The camera is recognized by the computer.

• Windows

When you connect the camera to your computer for the first time, the computer attempts to recognize the camera. Click "OK" to exit the message that is displayed. The camera is recognized as a "Removable Disk".

• Macintosh

The iPhoto program is the default application for managing digital images. When you connect your digital camera for the first time, the iPhoto application starts automatically, so close this application and start OLYMPUS Master.



Note

- The camera functions are disabled while the camera is connected to a computer.
- Connecting the camera to a computer via a USB hub may cause unstable operation. In this case, do not use a hub, but connect the camera directly to the computer.

Start up the OLYMPUS Master software

Windows


1 Double-click the “OLYMPUS Master” icon on the desktop.

- The main menu is displayed.
- When OLYMPUS Master is started up for the first time after installation, the “Registration” dialog box is displayed before the main menu. Follow the prompts and fill in the registration form.


Macintosh

1 Double-click the “OLYMPUS Master” icon in the “OLYMPUS Master” folder.

- The main menu is displayed.
- When OLYMPUS Master is started up for the first time, the “User Information” dialog box is displayed before the main menu. Enter your “Name” and “OLYMPUS Master Serial Number”, and select your region.
- After the “User Information” dialog box, the “Registration” dialog box is displayed. Follow the prompts and fill in the registration form.



OLYMPUS Master main menu



- 1 “Transfer Images” button**
Downloads images from the camera or other media.
- 2 “Browse” window is displayed.**
- 3 “Online Print” button**
The online print window is displayed.
- 4 “Print Images at Home” button**
The print menu is displayed.
- 5 “Create and Share” button**
Displays the editing menu.
- 6 “Backup Images” button**
Creates backup images.
- 7 “Upgrade” button**
Displays window for optional upgrade to OLYMPUS Master Plus.

To exit OLYMPUS Master

1 Click “Exit” on the main menu.

- OLYMPUS Master is exited.

Displaying camera images on a computer


Downloading and saving images

1 Click “Transfer Images”  on the OLYMPUS Master main menu.

- The menu for selecting the source is displayed.


2 Click “From Camera” .

- The window for selecting images is displayed. All the images in the camera are displayed.




3 Select the image files and click “Transfer Images”.

- A window indicating that the download is complete is displayed.



4 Click “Browse images now.”

- The downloaded images are displayed in the browse window.
- To return to the main menu, click “Menu” in the “Browse” window.




Connecting the camera to a computer

To disconnect the camera

1 Make sure that the card access lamp has stopped blinking.


Card access lamp




2 Make the following preparations for disconnecting the USB cable.


Windows 98SE

- ① Double-click the “My Computer” icon and right-click the “Removable Disk” icon to display the menu.
- ② Click “Eject” on the menu.



Windows Me/2000/XP

- ① Click the “Unplug or Eject Hardware” icon  in the system tray.
- ② Click the message that is displayed.
- ③ When a message is displayed saying that the hardware can be ejected safely, click “OK”.




Macintosh

- ① The trash icon changes to the eject icon when the “Untitled” or “NO_NAME” icon on the desktop is dragged. Drag and drop it on the eject icon.



3 Disconnect the USB cable from the camera.



Note

- Windows Me/2000/XP: When you click “Unplug or Eject Hardware”, a warning message may be displayed. Make sure that image data is not being downloaded from the camera and that all applications are closed. Click the “Unplug or Eject Hardware” icon again and disconnect the cable.


Viewing still pictures and movies

1 Click “Browse Images” on the OLYMPUS Master main menu.


- The “Browse” window is displayed.

2 Double-click the still picture thumbnail that you want to view.

Thumbnail



- The camera switches to view mode and the picture is enlarged.
- To return to the main menu, click “Menu” in the “Browse” window.



To view a movie

1 Double-click the movie thumbnail that you want to see in the “Browse” window.

- The camera switches to view mode and the first frame of the movie is displayed.

2 To play back the movie, click the playback button at the bottom of the screen.

The names and functions of the controller parts are shown below.



Item	Description
1 Playback slider	Move the slider to select a frame.
2 Time display	Displays the time that has elapsed during playback.
3 Playback (pause) button	Plays the movie. Functions as the pause button during playback.
4 Back button	Displays the previous frame.
5 Forward button	Displays the next frame.
6 Stop button	Stops playback and returns to the first frame.
7 Repeat button	Plays the movie repeatedly.
8 Volume button	Displays the volume adjustment slider.

Printing pictures

Pictures can be printed from the photo, index, postcard and calendar menus. The explanation below uses the photo menu.

1 Click “Print Images at Home”  on the OLYMPUS Master main menu.

- The print menu is displayed.

2 Click “Photo” .

- The “Photo Print” window is displayed.

3 Click “Settings” in the “Photo Print” window.

- The printer settings screen is displayed.
Make the necessary printer settings.






4 Select a layout and size.

- To print the date and time with your image, check the box next to “Print Date”, and select between “Date” and “Date & Time”.

5 Select the thumbnail image that you want to print and click “Add”.

- A preview of the selected image is displayed on the layout.

6 Select the number of copies.



7 Click “Print”.

- Printing starts.
- To return to the main menu, click “Menu” in the “Photo Print” window.

To download and save images to a computer without using OLYMPUS Master

This camera is compatible with USB mass storage. You can connect the camera to your computer using the USB cable provided with the camera to download and save images without using OLYMPUS Master. The following environment is required to use the USB cable to connect the camera to your computer.

Windows: Windows 98SE/Me/2000 Professional/XP

Macintosh: Mac OS 9.0 to 9.2/X



Note

- If your computer is running Windows 98SE, you will need to install the USB driver. Before connecting the camera to your computer with the USB cable, double-click the files from the following folders on the provided OLYMPUS Master CD-ROM.

(Drive name): \USB\INSTALL.EXE

- Data transfer is not guaranteed in the following environments, even if your computer is equipped with a USB port.
 - Windows 95/98/NT 4.0
 - Windows 98SE upgrades from Windows 95/98
 - Mac OS 8.6 or earlier
 - Computers with a USB port added by means of an extension card, etc.
 - Computers without a factory-installed OS and home-built computers

5 Getting to know your camera better

Shooting tips and information

Tips before you start taking pictures

The camera does not turn on even when a battery is loaded

The battery is not fully charged

- Charge the battery with the charger.

The battery is temporarily unable to function because of the cold

- Battery performance declines in low temperatures, and the charge may not be sufficient to turn on the camera. Remove the battery and warm it by putting it in your pocket for a while.

No picture is taken when the shutter button is pressed

The camera is in sleep mode

- To save battery power, the camera automatically goes into sleep mode and the monitor turns off if there is no operation when the camera is turned on (when the lens is extended and the monitor is on). No picture is taken even if the shutter button is fully pressed in this mode. Operate the zoom button or other buttons to restore the camera from sleep mode before taking a picture. If the camera is left for 15 minutes, it automatically turns off (the lens retracts and the monitor turns off). Press the **POWER** button to turn the camera on.

The mode dial is set to

- This is the playback mode for displaying pictures on the monitor. Set the mode dial to a shooting mode.

The mode dial is in the position of **GUIDE**


- No pictures can be taken when the shooting guide is being displayed. Turn the mode dial and set it to the position other than **GUIDE** in the shooting mode.

The flash is charging

- Wait until the  (flash charge) mark stops blinking before taking the picture.

The memory gauge is full



- No pictures can be taken when the memory gauge is full. Wait until there is space in the memory gauge.



The date and time have not been set

The camera has been used in the same conditions from the time of purchase

- No date and time have been set for the camera at the time of purchase. Set the date and time before using the camera.

  “Setting the date and time” (P. 36)

The battery has been pulled out of the camera.

- The date and time settings will be returned to the factory default settings if the camera is left without batteries for approximately 1 day. Before taking important pictures, check that the date and time settings are correct.


Shooting tips

Focusing on the subject

There are several ways to focus, depending on the subject.

When the subject is not in the center of the frame

- Place the subject in the center of the frame, lock the focus on the subject, and then recompose your picture.
- Set [AF MODE] to [iESP].

 “AF MODE Changing the focusing area” (P. 23)

The subject is moving quickly

- Focus the camera on a point roughly the same distance away as the subject you want to shoot (by pressing the shutter button halfway), and then recompose your picture and wait for the subject to enter the frame.

Subjects that are difficult to focus on

- Under certain types of conditions, it is difficult to focus using auto focus. The green lamp on the monitor lights, allowing you to check if the focus is locked.


The green lamp blinks. The subject cannot be brought into focus.



Subject with low contrast



Subject with an extremely bright area in the center of the frame




Subject without vertical lines

The green lamp lights, but the subject cannot be brought into focus.



Subjects at different distances



Fast-moving subject



The subject is not in the center of the frame

In these cases, focus (focus lock) on an object with high contrast at the same distance as the intended subject, recompose your shot and then take the picture. If the subject has no vertical lines, hold the camera vertically and focus the camera using the focus lock function by pressing the shutter button halfway, and then return the camera to the horizontal position while keeping the button pressed halfway and take the picture.

Taking pictures without blurring

Hold the camera correctly and press the shutter button gently to shoot the picture. You can reduce the blurring when shooting the picture in (AF) mode.

The factors that can cause the picture to blur are as follows:

- When you use the optical zoom, digital zoom, or zoom at such higher magnifications to shoot the picture
- When the shutter speed is set low to shoot a dark subject
- When the flash cannot be used or when a low shutter speed set **SCN** mode is selected.

Taking pictures without the flash

The flash fires automatically when there is insufficient light. If the subject is too far away, the flash may have no effect. Here is how to take pictures without the flash in this type of situation.


Set the camera to mode

- Because the sensitivity of the CCD increases automatically, you can hold the camera and take pictures in darker places with the flash off.

 “ Shooting pictures using image blur reduction” (P. 9)

Increase the [ISO] setting

- Increase the value of the [ISO] setting.

 “ISO Changing the ISO sensitivity” (P. 21)

The picture is too grainy

There are several factors that can cause the picture to appear grainy.

Using the digital zoom to take close-up pictures

- With the digital zoom, part of the image is cropped and enlarged. The greater the magnification, the grainier the picture appears.

 “DIGITAL ZOOM Zooming in on your subject” (P. 22)

Increasing the ISO sensitivity


- When you increase the [ISO] setting, “noise”, which appears as spots of unwanted color or unevenness in the color, can be introduced and give the picture a grainy appearance. This camera is equipped with a function to allow shooting at high sensitivity while suppressing noise; however, increasing the ISO sensitivity creates grainier pictures than when using a lower sensitivity.

 “ISO Changing the ISO sensitivity” (P. 21)






Taking pictures with the correct color

- The reason why there are differences between the colors in a picture and the actual colors taken and the actual color is the light source illuminating the subject. [WB] is the function that allows the camera to determine the correct colors. Normally, the [AUTO] setting provides the optimal white balance, but depending on the subject, it may be better to experiment with changing the [WB] setting.









- When the subject is in the shade on a sunny day
- When the subject is illuminated by both natural light and indoor lighting, such as when near a window
- When there is no white in the center of the frame

 “WB Adjusting the color of a picture” (P. 21)

Taking pictures of a white beach or snow scene

- Take pictures with  in **SCN** mode. Suitable for taking pictures on a sunny day at the beach or in the snow.
-  “**SCN** Shoot pictures by selecting a scene according to the situation” (P. 9)
- Often, bright subjects (such as snow) turn out darker than their natural colors. Adjust  toward [+] to make these subjects closer to their real shades. Conversely, when you are shooting dark subjects, it can be effective to adjust toward the [-]. Sometimes, using the flash may not produce the brightness (exposure) that was intended.
-  “ button Changing picture brightness” (P. 13)

Taking pictures of a subject against backlight

- With [ESP/] set to [], the picture can be taken based on the brightness at the center of the monitor without being affected by the light in the background.
-  “ESP/ Changing the area for measuring the brightness of a subject” (P. 22)
- Set the flash to  to activate fill-in-flash. You can shoot a subject against backlight without the face of the subject appearing dark.  is effective for shooting against backlight and under fluorescent and other artificial lightening.
-  “ button Flash shooting” (P. 13)

Additional shooting tips and information


Increasing the number of pictures that can be taken

There are two ways to record the pictures you take with this camera.

Recording pictures to the internal memory

- Pictures are recorded to the internal memory, and when the number of storable still pictures reaches 0, you must connect the camera to a computer to download the pictures, and then erase the pictures from the internal memory.

Using a card (optional)

- Pictures are recorded to the card when inserted in the camera. When the card is full, you download the pictures to a computer, and then either erase the pictures from the card or use a new card.
- Pictures are not recorded to the internal memory when a card is inserted in the camera. Pictures in the internal memory can be copied to the card using the [BACKUP] function.
-  “BACKUP Copying pictures in the internal memory to the card” (P. 33)
“The card” (P. 77)

Number of storable still pictures and recording length of movies

Still pictures


Image quality	Image size	Number of storable still pictures			
		Internal memory		Using a 128 MB card	
		With sound	Without sound	With sound	Without sound
SHQ	3072 × 2304	5	5	36	36
HQ	3072 × 2304	11	11	71	73
SQ1	2560 × 1920	15	16	102	105
	2304 × 1728	19	19	124	128
	2048 × 1536	23	24	156	163
SQ2	1600 × 1200	28	30	185	194
	1280 × 960	43	46	285	307
	1024 × 768	64	71	420	469
	640 × 480	97	116	614	726

Movie

Image quality	Image size	Recording length (in minutes)	
		Internal memory	Using a 128 MB card
SHQ	640 × 480 (15 frames/sec.)	17	112
HQ	320 × 240 (15 frames/sec.)	50	333
SQ	160 × 120 (15 frames/sec.)	129	848

Using a new card

- If you use a non-Olympus card or a card used for another application, such as for a computer, the message [CARD ERROR] is displayed. To use this card with this camera, use the [FORMAT] function to format the card.

 "MEMORY FORMAT (FORMAT) Formatting the internal memory or card" (P. 33)

Lamp indicators

This camera uses several lamps to indicate the camera status.

Lamp	Status
Self-timer lamp	The lamp lights for approximately 10 seconds, blinks for approximately 2 seconds, and then the picture is taken.
Card access lamp	Blinking: A picture is being recorded, the camera is reading a movie, or images are being downloaded (when connected to a computer). <ul style="list-style-type: none">• Do not do any of the following while the card access lamp is blinking. Doing so may prevent the image data from being saved and render the internal memory or card unusable.<ul style="list-style-type: none">• Open the battery compartment/card cover• Remove the battery.• Connect or disconnect the AC adapter.
Green lamp of the LCD monitor	Lit: The focus and exposure are locked. Blinking: The focus and exposure are not locked. <ul style="list-style-type: none">• Release your finger from the shutter button, re-position the AF target mark on the subject and press the shutter button halfway again.

Extending the useful life of the battery

- Performing any of the following operations when not actually taking pictures can deplete the battery power.
 - Repeatedly pressing the shutter button halfway
 - Repeatedly using the zoom
- To save battery power, turn off the camera whenever it is not in use.

Functions that cannot be selected from menus

- Some items may not be selectable from the menus when using the arrow pad ($\triangle \nabla \leftarrow \rightarrow$).
 - Items that cannot be set with the current shooting mode
 - Items that cannot be set because of an item that has already been set: [s], [FLASH MODE], etc.
 - Items that cannot be set because the pictures taken by other camera will be edited.
- Some functions cannot be used when there is no card in the camera.
[PANORAMA], [FORMAT], [BACKUP], [PRINT ORDER], [REDEYE FIX], [BLACK & WHITE], [SEPIA], [FRAME], [TITLE], [CALENDAR], [BRIGHTNESS], [SATURATION], [ALBUM ENTRY], ALBUM

Selecting the optimal record mode

A record mode expresses a combination of desired image size and compression level. Use the following examples to help determine the optimal record mode when shooting.

To print large images on full-size paper/To edit and process images on a computer

- [SHQ] or [HQ]

To print postcard-size images


- [SQ1]

To send as an e-mail attachment or post on a web site

- [SQ2]

 "IMAGE QUALITY Changing the image quality" (P. 19)

To return the settings of functions to default settings

- If the settings such as [IMAGE QUALITY] or flash settings (excluding ) and **SCN** are changed according to the shooting, the changed settings can be maintained even after the power is turned off. Change [RESET] to [YES] to return the settings to default settings.

 RESET Change the shooting functions back to default settings (P. 20)

Confirming the exposure when the monitor is difficult to see outdoors


The monitor may be difficult to see and the exposure difficult to confirm when shooting outdoors.



Press the button repeatedly to display the histogram

- Set the exposure so that the graph is concentrated on the outer edges and the graph is balanced on both sides.

How to read the histogram

- ① If the peak fills too much of the frame, the image will appear mostly black.
- ② If the peak fills too much of the frame, the image will appear mostly white.
- ③ The part indicated in green in the histogram shows the luminance distribution within the AF target mark.



  button Changing the information displays /Display the menu guide" (P. 15)

Playback help

The red-eye cannot be fixed

- Depending on the picture, the red-eye may not be fixed. Also, parts except the eye may be fixed.





The picture cannot be registered in the album

- Up to 200 pictures can be registered in each album.
- The same picture cannot be registered in several albums.




Playing back the picture in the internal memory

- When a card has been inserted in the camera, the picture in the internal memory cannot be played back. Pull out the card before operating the camera.



Understanding the settings and other information of pictures taken

- Play back a picture, and press the  button. Press the  button repeatedly to change the amount of information displayed.
-   button Changing the information displays /Display the menu guide” (P. 15)

Quickly displaying a desired picture

- Use the album function. You can create up to 12 albums and enter the pictures on a card to the albums. To view the pictures, set the mode dial to , and then select an album from the top menu to play back. The same picture cannot be entered in multiple albums.
-  “ALBUM ENTRY Adding pictures to an album” (P. 29)
“Album playback menus” (P. 31)
- Press W on the zoom button to view the pictures as thumbnails (index display) or in a calendar format (calendar display).
-  “Zoom button Zooming while shooting/close-up playback” (P. 11)

Erasing sound recorded to still pictures

- Once sound is added to a picture, it is not possible to erase the sound. In this case, make a re-recording with silence. Sound recording is not possible if there is insufficient space in the internal memory or on the card.
-   Adding sound to still pictures” (P. 28)

Viewing the entire picture on a computer screen

The size of the picture displayed on a computer screen changes depending on the computer settings. When the monitor setting is 1,024 × 768 and you are using Internet Explorer to view a picture with an image size of 2,048 × 1,536 at 100%, the entire picture cannot be viewed without scrolling. There are several ways you can view the entire picture on the computer screen.










View the picture using image browsing software












- Install the OLYMPUS Master software from the provided CD-ROM.

Change the monitor setting

- The icons on the computer desktop may be rearranged. For details of changing the settings on your computer, refer to the computer's instruction manual.

When you get an error message on the camera...

Monitor indication	Possible cause	Corrective action
 CARD ERROR	There is a problem with the card.	This card cannot be used. Insert a new card.
 WRITE-PROTECT	Writing to the card is prohibited.	The recorded image has been protected (read-only) on a computer. Download the image to a computer and cancel the read-only setting.
 MEMORY FULL	The internal memory has no available memory and cannot store any new data.	Insert a card or erase unwanted data. Before erasing, backup the data of important pictures using the card, or download such pictures to a computer.
 CARD FULL	The card has no available memory and cannot store any new data.	Replace the card or erase unwanted data. Before erasing, download important pictures to a computer.
 NO PICTURE	There are no pictures in the internal memory or on the card.	The internal memory or the card contains no pictures. Record pictures.
 PICTURE ERROR	There is a problem with the selected picture and it cannot be played back on this camera.	Use image processing software to view the picture on a computer. If that cannot be done, the image file is damaged.
 CARD-COVER OPEN	The battery compartment/card cover is open.	Close the battery compartment/card cover.
 BATTERY EMPTY	The battery is empty.	Charge the battery.
 Y/M/D	When the camera is used for the first time or the battery has been removed for a long time, the date and time are on the factory default setting.	Set the date and time.

Monitor indication	Possible cause	Corrective action
	This card cannot be used in this camera. Or, the card is not formatted.	Format the card or replace. <ul style="list-style-type: none"> • Select [POWER OFF] and press . • Insert a new card. • Select [FORMAT] ► [YES] and press . All data on the card is erased.
	There is an error in the internal memory.	Select [MEMORY FORMAT] ► [YES] and press  . All data in the internal memory is erased.
 NO CONNECTION	The camera is not connected to the printer correctly.	Disconnect the camera and connect it again correctly.
 NO PAPER	There is no paper in the printer.	Load some paper in the printer.
 NO INK	The printer has run out of ink.	Replace the ink cartridge in the printer.
 JAMMED	The paper is jammed.	Remove the jammed paper.
SETTINGS CHANGED	The printer's paper tray has been removed or the printer has been operated while changing settings on the camera.	Do not operate the printer while changing settings on the camera.
 PRINT ERROR	There is a problem with the printer and/or camera.	Turn off the camera and printer. Check the printer and remedy any problems before turning the power on again.
 CANNOT PRINT	Pictures recorded on other cameras may not be printed on this camera.	Use a computer to print.

Functions available in shooting modes and scenes

Some functions cannot be set in certain shooting modes. For more details, refer to the table below.

Grayed out areas () in the **SCN** column indicate that to enable the shooting scene in **SCN** mode, there are restrictions to the functions that can be set.

 "Functions with restrictions in shooting scenes" (P. 72)

Functions available in shooting modes

Function	Shooting mode			SCN	
					
	P	AUTO			
	✓	✓	✓	✓	✓
Flash	✓	✓	✓		—
	✓	✓	✓		✓
	✓	✓	✓		✓
Optical zoom	✓	✓	✓		✓
WB	✓	—	✓	✓	✓
ISO	✓	—	—		—
DRIVE	✓	—	✓		—
ESP/ 	✓	—	✓		✓
IMAGE QUALITY	✓	✓	✓		✓
DIGITAL ZOOM	✓	—	✓		✓
AF MODE	✓	—	✓		—
	✓	—	✓		—
PANORAMA	✓	—	✓		—
MEMORY FORMAT (FORMAT)	✓	✓	✓	✓	✓
BACKUP	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓
PW ON SETUP	✓	✓	✓	✓	✓
COLOR	✓	✓	✓	✓	✓
BEEP	✓	✓	✓		✓
	✓	✓	✓		✓
SHUTTER SOUND	✓	✓	✓		—
REC VIEW	✓	✓	✓		—
FILE NAME	✓	✓	✓	✓	✓
PIXEL MAPPING	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓
DUALTIME	✓	✓	✓	✓	✓
ALARM CLOCK	✓	✓	✓	✓	✓

Function	Shooting mode			SCN	
	P	AUTO			
VIDEO OUT	✓	✓	✓	✓	✓
	✓	✓	✓	✓	—
FRAME ASSIST	✓	✓	✓	✓	—

Functions with restrictions in shooting scenes

Scene																
Flash	✓	✓	✓	✓	—	✓	—	—	—	—	—	—	—	—	✓	✓
	✓	✓*1	✓*1	✓	✓	✓*1	✓*1	✓*1	✓	✓	—	✓	✓	✓	✓	—
	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	—	—	—	*4	—
Optical zoom	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓	✓	✓	—
ISO	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	✓
DRIVE	✓	✓	—	✓	✓	✓	—	—	✓	✓	—	—	—	✓	✓	✓
ESP/	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
IMAGE QUALITY	✓	✓	✓	✓	✓ ²	✓	✓	✓	✓	✓	*3	✓ ²	✓	✓	✓	✓
DIGITAL ZOOM	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	—	✓	✓	✓	✓
AF MODE	✓	✓	✓	✓	✓	—	✓	—	✓	✓	✓	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	
PANORAMA	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	—	—	—	✓	✓	
BEEP	✓	✓	✓	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓
SHUTTER SOUND	✓	✓	✓	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓
REC VIEW	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	—	—	—	✓	—	

*1 [s] is not available.

*2 Only the picture quality below [2048 x 1536] is available.

*3 The picture quality is fixed to [640 x 480].

*4 AF lock is on.

Aperture

The adjustable lens opening which controls the amount of light that enters the camera. The larger the aperture, the shorter the depth of field and the fuzzier the background. The smaller the aperture, the greater the depth of field and the sharper the background. Larger aperture values indicate smaller apertures, and smaller aperture values indicate larger apertures.

CCD (Charge-Coupled Device)

This converts light passing through the lens into electrical signals. On this camera, light is picked up and converted into RGB signals to build a single image.

Contrast Detection Method

This is used to measure the distance to the subject. The camera determines if the image is focused by the level of contrast in the subject.

Conventional Photograph

This refers to recording images using silver halide (the method for recording images in conventional, non-digital photography). This system is in contrast to still video and digital photography.

DCF (Design Rule for Camera File System)

A standard for image files by the Japan Electronics and Information Technology Industries Association (JEITA).

DPOF (Digital Print Order Format)

This is for saving desired print settings on digital cameras. By entering which images to print and the number of copies of each, the user can easily have the desired images printed by a printer or print lab that supports the DPOF format.

Eclipsing (Vignetting)

This refers to when an object obscures part of the field of view so that the whole subject is not photographed. Vignetting also refers to when the image seen through the viewfinder does not exactly match the image shot through the objective lens, so the photographed image includes objects not seen through the viewfinder. In addition, vignetting can occur when an incorrect lens hood is used, causing shadowing to appear in the corners of the image.

ESP (Electro-Selective Pattern) Light Metering/Digital ESP Light Metering

This determines the exposure by metering and calculating the light levels in the center and other areas of the image separately.

EV (Exposure Value)

A system for measuring exposure. EV0 is when the aperture is at F1 and the shutter speed is 1 second. The EV then increases by 1 each time the aperture increases by one F stop or the shutter speed increases by one increment. EV can also be used to indicate brightness and ISO.

Exposure

The amount of light used to capture an image. The exposure is determined by the time the shutter is open (shutter speed) and the amount of light that passes through the lens (aperture).

Image size

The size of an image expressed by the number of pixels that make up the image. For instance, a picture taken with an image size of 640 × 480 fills the computer screen when the monitor setting is 640 × 480. However, if the monitor setting is 1,024 × 768, the picture only takes up part of the screen.

ISO

A method for indicating film speed by the International Organization for Standardization (ISO) (ex.g|ISO100h). Higher ISO values indicate greater sensitivity to light, so images can be exposed even in low-light conditions.

JPEG (Joint Photographic Experts Group)

A compression format for still images. Photographs (pictures) taken using this camera are recorded onto the card in JPEG format. By downloading these images to a computer, users can edit them using graphics application software or view the images using an Internet web browser.

NTSC (National Television Systems Committee) / PAL (Phase Alternating Line)

Television formats. NTSC is mainly used in Japan, North America and Korea. PAL is mainly used in Europe and China.

PictBridge

A standard for connecting digital cameras and printers of different makers and printing out pictures directly.

Pixels

A pixel is the smallest unit (dot) used to make up an image. Clear large-sized printed images require millions of pixels.

Program auto

Also called Program AE mode. The camera automatically sets the best shutter speed and aperture for the shot.

Sleep mode

A mode designed to save battery life. The camera automatically enters the sleep mode if you do not operate it for a certain time. To exit the sleep mode, use any button on the camera (shutter button, arrow pad ($\triangle \nabla \langle \rangle$), etc.).

TFT (Thin-Film Transistor) Color Monitor

A transistor color monitor constructed using thin-film technology.

Camera care

Cleaning the camera

Exterior:

- Wipe gently with a soft cloth. If the camera is very dirty, soak the cloth in mild soapy water and wring well. Wipe the camera with the damp cloth and then dry it with a dry cloth. If you have used the camera at the beach, use a cloth soaked in clean water and wrung well.

Monitor:

- Wipe gently with a soft cloth.

Lens:

- Blow dust off the lens with a commercial blower, then wipe gently with a lens cleaner.

Battery/Charger:

- Wipe gently with a soft, dry cloth.



Note

- Do not use strong solvents such as benzene or alcohol, or chemically treated cloth.
- Mold may form on the lens surface if the lens is left dirty.

Storage

- When storing the camera for extended periods, remove the battery, AC adapter and card, and keep in a cool, dry place that is well ventilated.
- Periodically insert the battery and test the camera functions.



Note

- Avoid leaving the camera in places where chemical products are handled since this may result in corrosion.

Battery and charger

- This camera uses one Olympus lithium ion battery. No other type of batteries can be used.
- Power consumption by the camera varies depending on which functions are used.
- During the conditions described below, power is consumed continuously and the battery becomes exhausted quickly.
 - The zoom is used repeatedly.
 - The shutter button is pressed halfway repeatedly in shooting mode, activating the auto focus.
 - A picture is displayed on the monitor for an extended period of time.
 - The camera is connected to a computer or printer.
- Using an exhausted battery may cause the camera to turn off without displaying the battery level warning.
- The rechargeable battery is not fully charged at the time of purchase. Charge the battery fully with the LI-40C charger before use.
- This camera uses a charger specified by Olympus. Do not use any other type of charger.
- The charger can be used within the range of AC 100 V to AC 240 V (50/60 Hz). When using the charger abroad, you may need a plug adapter to convert the plug to the shape of the AC wall outlet. For details, ask at your local electrical shop or travel agent.
- Do not use travel voltage converters as they could damage your charger.

Useful use of the accessories

The card

Pictures can be recorded on the optional card.

The internal memory and card are the camera's media for recording pictures, similar to film in a film camera.

Pictures recorded to the internal memory or card can be easily erased on the camera or processed using a computer.

Unlike portable storage media, the internal memory cannot be removed or exchanged.


The number of recordable pictures can be increased by using a card with a larger capacity.

① Index area

You can use this space to write the contents of the card.

② Contact area

The part where the data transferred from the camera enters the card.



Compatible cards

xD-Picture Card (16MB – 1GB)

Using the internal memory or card

You can confirm on the monitor whether the internal memory or card is being used during shooting and playback operations.

Shooting mode




Playback mode



Memory indicator

Inserting and removing the card


- 1 Turn off the camera
- 2 Open the battery compartment/card cover.



Battery compartment/card cover

Inserting the card


- 3 Orient the card as shown, and insert it into the card slot as shown in the illustration.
- Insert the card straight in.
 - Insert the card until it clicks into place.




Removing the card

- 3 Push the card all the way in and release slowly.


- The card protrudes slightly and stops.



- Grasp the card and remove.




- 4 Close the battery compartment/card cover.



! Note

- The card access lamp blinks while the camera is reading the images. Reading of images may take some time. Do not open the battery compartment/ card cover while the card access lamp is blinking. Doing so may damage the data in the internal memory or the card and render the internal memory or card unusable.



AC adapter

An AC adapter is useful for time-consuming tasks such as image downloads to a computer or when running a slideshow for a long period of time. To use an AC adapter for this camera, the multi-adapter (CB-MA1/accessory) is required. Do not use any other AC adapter with this camera.

! Note

- Do not remove or load the battery or connect or disconnect the AC adapter or the multi-adapter while the camera is turned on. Doing so could affect the camera's internal settings or functions.
- The AC adapter can be used within the range of AC 100 V to AC 240 V (50/60 Hz).
- When using abroad, you may need a plug adapter to convert the plug to match the AC wall outlet. For details, ask at your local electrical shop or travel agent.
- Do not use travel voltage converters as they could damage your AC adapter.
- The camera is not water resistant during AC adapter use.
- Be sure to read the instruction manual for the AC adapter.

Safety Precautions

Caution for Usage Environment

- To protect the high-precision technology contained in this product, never leave the camera in the places listed below, no matter if in use or storage:
 - Places where temperatures and/or humidity are high or go through extreme changes. Direct sunlight, beaches, locked cars, or near other heat sources (stove, radiator, etc.) or humidifiers.
 - In sandy or dusty environments.
 - Near flammable items or explosives.
 - In wet places, such as bathrooms or in the rain. When using products with weatherproof designs, read their manuals as well.
 - In places prone to strong vibrations.
- Never drop the camera or subject it to severe shocks or vibrations.
- When mounted on a tripod, adjust the position of the camera with the tripod head. Do not twist the camera.
- Do not touch electric contacts on cameras.
- Do not leave the camera pointed directly at the sun. This may cause lens or shutter curtain damage, color failure, ghosting on the CCD, or may possibly cause fires.
- Do not push or pull severely on the lens.
- Before storing the camera for a long period, remove the battery. Select a cool, dry location for storage to prevent condensation or mold from forming inside the camera. After storage, test the camera by turning it on and pressing the shutter release button to make sure that it is operating normally.
- Always observe the operating environment restrictions described in the camera's manual.

Battery Handling Precautions

- This camera uses a lithium ion battery specified by Olympus. Do not use any other type of battery. For safe and proper use, read the battery's instruction manual carefully before using it.
- If the battery's terminals get wet or greasy, camera contact failure may result. Wipe the battery well with a dry cloth before use.
- Always charge a battery when using it for the first time, or if it has not been used for a long period.
- When operating the camera with battery power at low temperatures, try to keep the camera and spare battery as warm as possible. A battery that has run down at low temperatures may be restored after it is warmed at room temperature.
- The number of pictures you can take may vary depending on the shooting conditions or battery.
- Before going on a long trip, and especially before traveling abroad, purchase extra batteries. A recommended battery may be difficult to obtain while traveling.
- Please recycle batteries to help save our planet's resources. When you throw away dead batteries, be sure to cover their terminals and always observe local laws and regulations.

LCD Monitor

- Do not push the monitor forcibly; otherwise the image may become vague, resulting in a playback mode failure or damage to the monitor.
- A strip of light may appear on the top/bottom of the monitor, but this is not a malfunction.
- When a subject is viewed diagonally in the camera, the edges may appear zigzagged on the monitor. This is not a malfunction; it will be less noticeable in playback mode.
- In places subject to low temperatures, the LCD monitor may take a long time to turn on or its color may change temporarily. When using the camera in extremely cold places, it is a good idea to occasionally place it in a warm place. An LCD monitor exhibiting poor performance due to low temperatures will recover in normal temperatures.
- The LCD used for the monitor is made with high-precision technology. However, black spots or bright spots of light may appear constantly on the LCD Monitor. Due to its characteristics or the angle at which you are viewing the monitor, the spot may not be uniform in color and brightness. This is not a malfunction.

Legal and Other Notices

- Olympus makes no representations or warranties regarding any damages, or benefit expected by using this unit lawfully, or any request from a third person, which are caused by the inappropriate use of this product.
- Olympus makes no representations or warranties regarding any damages or any benefit expected by using this unit lawfully which are caused by erasing picture data.

Disclaimer of Warranty

- Olympus makes no representations or warranties, either expressed or implied, by or concerning any content of these written materials or software, and in no event shall be liable for any implied warranty of merchantability or fitness for any particular purpose or for any consequential, incidental or indirect damages (including but not limited to damages for loss of business profits, business interruption and loss of business information) arising from the use or inability to use these written materials or software or equipment. Some countries do not allow the exclusion or limitation of liability for consequential or incidental damages, so the above limitations may not apply to you.
- Olympus reserves all rights to this manual.

Warning

Unauthorized photographing or use of copyrighted material may violate applicable copyright laws. Olympus assumes no responsibility for unauthorized photographing, use or other acts that infringe upon the rights of copyright owners.

Copyright Notice

All rights reserved. No part of these written materials or this software may be reproduced or used in any form or by any means, electronic or mechanical, including photocopying and recording or the use of any type of information storage and retrieval system, without the prior written permission of Olympus. No liability is assumed with respect to the use of the information contained in these written materials or software, or for damages resulting from the use of the information contained therein. Olympus reserves the right to alter the features and contents of this publication or software without obligation or advance notice.

FCC Notice

- **Radio and Television Interference**

Changes or modifications not expressly approved by the manufacturer may void the user's authority to operate this equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.














This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:




 - Adjust or relocate the receiving antenna.
 - Increase the distance between the camera and receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult your dealer or an experienced radio/TV technician for help. Only the OLYMPUS-supplied USB cable should be used to connect the camera to USB enabled personal computers (PC).

Any unauthorized changes or modifications to this equipment would void the user's authority to operate.

Index


 Red-eye reduction flash	13
 Fill-in flash	13
 Flash off	13
 Super macro mode	13
 Macro mode	13
 button (print)	14
 button (exposure compensation)	13
 button (self-timer)	13
 button (flash mode)	13
 button (macro)	13
 button	15
 button (OK/FUNC)	10
 button (erase)	14

A



AC adapter	79
AF lock	8
AF MODE	23
ALARM CLOCK 	37
ALBUM	30
ALBUM ENTRY	29
Album playback	31
ALL ERASE 	30
ALL INDEX	42
ALL PRINT	42
All-frame reservation 	46
Arrow pad	10
AUTO (Auto-flash)	13
AUTO (Full auto mode)	10
AUTO (ISO)	21
AUTO (WB) WB AUTO	21
Auto focus	61
AV cable	38

B



BACKUP	33
Battery	76
Battery check	69

Battery compartment/card cover	78
BEEP	34
Beep sound 	34
BGM	24
BLACK & WHITE	26
BRIGHTNESS	27



C

CALENDAR	26, 27
Calendar display	12
Card	33, 77
Card access lamp	54, 65, 79
CCD	35, 73
Close-up playback 	12
Cloudy day 	21
COLOR	34
Compression	19
Connector cover	38, 52
CUSTOM PRINT	42

D

Date and time 	36
DIGITAL ZOOM	22
Direct printing	40
DPOF	45, 73
DRIVE	22
DUALTIME 	36

E

EASY PRINT	40
EDIT	26
Erase	30
Erasing pictures	14
Error message	69
ESP	22, 73
ESP/ 	22
EV	13, 73
Exposure	8
Exposure compensation 	13

F	
FADER	24
FILE NAME	35
File name	35
Flash	13
Flash charge	59
Flash mode	12
Fluorescent lamp 1/2/3	21
Focus	8, 9
Focus lock	8
FORMAT ^{AF}	33
FRAME	26
FRAME ASSIST	15, 38
Frame number	32
Function menu	10

G	
GUIDE SHOOTING GUIDE	9

H	
High speed sequential shooting	22
Histogram display	15, 38, 66
HQ	19

I	
iESP	23
Image blur reduction	9
IMAGE QUALITY	19
Image size	19, 73
INDEX	26, 27
Index display	12
Information display	15
Internal memory	33
ISO	21, 74


J	
JPEG	74

L	
Lithium ion battery	76



M	
MENU button (MENU)	11
MEMORY FORMAT	33
Memory gauge	59
Menu	16
Menu guide	15
Microphone	28
Mode dial	9
Monitor brightness adjustment	36
MOVIE PLAY	25
MULTI PRINT	42
Multi-connector	38, 40, 52
N	
NTSC	38, 74
Number of storable still pictures	64

O	
OLYMPUS Master	48
Optical zoom	11, 22











P	
P (Program auto)	10
P/AUTO	10
PAL	38, 74
PANORAMA	23
PC	52
PictBridge	40, 74
Picture rotation	28
PIXEL MAPPING	35
Pixels	74
Playback mode menu	24
Playback mode	8, 10, 15, 16, 24
Playback on a TV	38
Playing time/Total recording time	25
POWER button	8
Press fully	8
Press halfway	8
PRINT ORDER	42
PRINT ORDER	28
Print settings	45



Printing pictures	39
Program auto	74
Protect 	28
PW ON SETUP	34

R


REC VIEW	35
Recording sound	28
Recording sound with still pictures 	23
REDEYE FIX	26
RESET	20
Resizing 	26

S



SCN	9, 20
SATURATION	27
SCREEN SETUP	34
SEL. ALBUM	31
SEL. IMAGE	29, 30, 32
SELECT JACKET	32
Selecting a language 	34
Self-timer lamp	13, 65
Self-timer 	13
SEPIA	26
Sequential shooting 	22
SET ALL	29
SET CALENDAR	29
SETUP	33
SHOOT & SELECT 1/2  	21
Shooting mode	8, 11, 15, 16, 19
Shooting mode menu	19
Shooting movies 	9
Shooting still pictures 	8
SHQ	19
Shutter button	8
SHUTTER SOUND	34
Single-frame reservation 	46
Single-frame shooting 	22
Sleep mode	74
SLIDE	24
SLIDESHOW 	24

SPOT (AF MODE)	23
Spot metering 	22
SQ1	19
SQ2	19
STANDARD	40
Sunny day 	21

T

TITLE	27
Top menu	16
Tungsten light 	21
TYPE	24

U

Under Water Macro 	8
Under Water Wide1 	8
UNDO ALL	32
UNDO ENTRY (ALBUM ENTRY)	32
USB cable	40, 48, 52, 55
USB driver	49, 58

V

VIDEO OUT	38
VOLUME	35

W

White balance WB	21
------------------	----

X

xD-Picture Card	23, 77
-----------------	--------

Z

Zoom	11, 22
ZOOM (Slideshow)	24
Zoom button	11

OLYMPUS®

<http://www.olympus.com/>

OLYMPUS IMAGING CORP.

Shinjuku Monolith, 3-1 Nishi-Shinjuku 2-chome, Shinjuku-ku, Tokyo, Japan

OLYMPUS IMAGING AMERICA INC.

Two Corporate Center Drive, P.O. Box 9058, Melville, NY 11747-9058, U.S.A. Tel. 631-844-5000

Technical Support (USA)

24/7 online automated help: <http://www.olympusamerica.com/support>

Phone customer support: Tel. 1-888-553-4448 (Toll-free)

Our phone customer support is available from 8 am to 10 pm

(Monday to Friday) ET

E-Mail: distec@olympus.com

Olympus software updates can be obtained at: <http://www.olympus.com/digital>

OLYMPUS IMAGING EUROPA GMBH

Premises: Wendenstrasse 14-18, 20097 Hamburg, Germany

Tel: +49 40-23 77 3-0 / Fax: +49 40-23 07 61

Goods delivery: Bredowstrasse 20, 22113 Hamburg, Germany

Letters: Postfach 10 49 08, 20034 Hamburg, Germany

European Technical Customer Support:

Please visit our homepage <http://www.olympus-europa.com>

or call our TOLL FREE NUMBER* : **00800 - 67 10 83 00**

for Austria, Belgium, Denmark, Finland, France, Germany, Italy, Luxemburg, Netherlands,
Norway, Portugal, Spain, Sweden, Switzerland, United Kingdom

* Please note some (mobile) phone services providers do not permit access or request an
additional prefix to +800 numbers.

For all European Countries not listed and in case that you can't get connected
to the above mentioned number, please make use of the following

CHARGED NUMBERS: +49 180 5 - 67 10 83 or +49 40 - 237 73 899

Our Technical Customer Support is available from 9 am to 6 pm MET (Monday to Friday)