

Kabel USB 2.0 Typ A - Mini B (B 4-pin) 1.8 m

Canon EOS Kiss Digital
Canon PowerShot A 310
Canon PowerShot A 75
Canon Powershot S 60
Canon Sharp VE-LC2S
Casio QV R51
Contax SL300R T
Epson Kodak DC290
Epson PhotoPC 3100 Z
HP PhotoSmart 315
JVC GC X 1
JVC GC X 3
Kodak CX 7430
Kodak DC 4800
Kodak DX 3215
Kodak DX 3500
Kodak DX 3600
Kodak DX 3600 Zoom
Kodak DX 3700
Kodak DX 3900
Kodak DX 3900 Zoom
Kodak DX 4900 Zoom
Kodak DX 7630
Kodak EasyShare CX 7310
Konica Minolta Dimage G 400
Kyocera Finecam L 30
Kyocera Finecam M 400 R
Kyocera Finecam M 410 R
Minolta Dimage G 400
Olympus C 1
Olympus C 1 Zoom
Olympus C 2
Olympus C 200 Zoom
Olympus C 2040 Zoom
Olympus C 2100 Ultra Zoom
Olympus C 3000 Zoom
Olympus C 3030 Zoom
Olympus C 3040 Zoom
Olympus C 4040 Zoom
Olympus C 5060 Zoom
Olympus C 700 Ultra Zoom
Olympus C 760 Ultra Zoom
Olympus E 10
Olympus E 100 RS
Olympus E 20 P
Panasonic Lumix DMC-FZ2
Panasonic Lumix DMC-LC1
Panasonic Lumix DMC-LC33
Ricoh Caplio RR 330
Sony DSC F 505 V
Sony DSC F 828
Sony DSC P 10
Sony DSC P 43
Sony DSC P 73



Sony DSC P 8
Sony DSC U 40
Sony DSC U 50
Sony DSC V 1
Sony DSC W 1
Sony DSC-F505
Sony DSC-S30
Sony DSC-S50
Sony DSC-S70

