




StarLite® QL



Step 1 Figure a



Step 1 Figure b



Step 2 Figure a



Step 2 Figure b



Step 3 Figure a



Step 3 Figure b



Step 3 Figure c

## StarLite® QL

The StarLite® QL is features a quick locking design for quick secure set up and tear down.

The StarLite® QL comes with:

- StarLite® QL Lamp Fixture
- Twist lock SwivelMount
- Power cord with 20 amp industrial switch

### Safety Precautions

- a. The StarLite QL is designed for use with a high heat resistant SoftBox such as the Photoflex® SilverDome® NXT, OctoDome® NXT or MovieDome®. Be sure that the SoftBox that you are using is rated for use with hot lights as you could create a hazardous situation.
- b. Do not operate the StarLite® QL in moist or wet conditions as this will create a hazardous situation.
- c. Always turn off power and unplug the power cable before changing lamps.

*NOTE: We recommend that you assemble the SoftBox to the StarLite® OctoConnector. For instructions on assembly of your particular SoftBox, refer to the instructions included with your SoftBox or go to [www.Photoflex.com](http://www.Photoflex.com) for further details.*

### Step 1 – Assembly of the StarLite® head to the twist lock swivel

- a. Slide the bottom of the StarLite® head onto the receiving channel of the twist lock SwivelMount
- b. Securely tighten the set screw on the swivel to lock in place


### Step 2 - Locking the StarLite® head and swivel assembly to the StarLite® OctoConnector

- a. With the SoftBox assembled and face down on a clean flat surface; place the StarLite® head over the connector, matching the 3 metal posts on the head with the three corresponding key holes.
- b. Insert the StarLite® head into the SoftBox connector and turn clockwise to lock in place.


*Note: the locking pin will click into place through the plate confirming you have correctly assembled together.*

### Step 3 – Placing StarLite® & SoftBox assembly onto your LiteStand

- a. With the StarLite® head securely attached to the swivel and the SoftBox, lift the assembly and place the 5/8 inch receiver over the stud of your LiteStand
- b. Set the receiver onto the stud making sure that it drops all the way down and then tighten the set screw to properly secure it.
- c. Make sure that the twist lock handle is tightened securely to prevent unwanted tilt before letting go of the assembly on the LiteStand.



Step 4 Figure a



Step 4 Figure b



Step 4 Figure c



Step 5 Figure a

#### Step 4 – Installing lamp and power cable

- a. Insert StarLite® QL lamp into the porcelain socket and turn clockwise until secure.

*Note: Do not over tighten as you may damage the lamp.*

- b. Plug the PC connector on one end of the Cable into the AC-Inlet on the rear of the StarLite® head.
- c. The power cable has a heavy duty 20 amp inline rocker switch. Make sure that the switch is in the off position before plugging it into the live power.

#### Step 5 – Breaking down the StarLite® QL & SoftBox assembly

To disassemble the completed StarLite® QL and SoftBox assembly perform the previous steps 1-4 in reverse.

*Note: To detach the StarLite® head from the SoftBox connector pull back on the spring loaded lever to release the locking pin and simultaneously turn the StarLite® head counter clockwise to release.*

**Customer Support (800) 486-2674**  
**email: sales@photoflex.com**

Corporate Office (831) 786-1370 • FAX (831) 786-1371  
97 Hangar Way, Watsonville, CA 95076

#### **PHOTOFLEX® WARRANTY**

- Warranties only cover manufacturer's defects and workmanship
- We reserve the right to inspect all merchandise returned (end users and dealers) for warranty fulfillment.
- All returns must be accompanied by a receipt showing date of purchase.
- Freight must be paid by the customer or dealer.
- Warranties are valid only from date of Original Purchase.
- Warranty does not cover normal wear and tear.