Firmware version: A6





General notes

B2 AirTTL

The B2 is designed to be "future proof" and the firmware can be upgraded via the USB port. Be sure not to miss important upgrades for your product. Register your B2 at Profoto.com/register to receive first-hand information of future upgrades for your Profoto product.

This release notes covers firmware specific information. Detailed functionality descriptions can be found in the user guide.

New in firmware version A6

- Adjusted power control to improve light output and color temperature stability.
- Improved battery level representation on display.
- Fixed bug to ensure that Air is completely disabled when switched off in sync settings.
- Added HSS compatibility with Air Remote TTL-S version A3 (released 2017.02) and later versions.

Check firmware version

When the B2 is switched off, press and hold both buttons for model light [1 and 2] and then press and hold the ON button [3] until the B2 switches on and the installed firmware version will be displayed.



Profoto Air Remote compatibility

The optional Profoto Air Remotes below are all tested with B2 250 AirTTL firmware version A6.

Profoto Air Remote options	TTL, HSS, Remote Control and sync	Remote Control and sync	Sync only
Air Remote TTL-C (For Canon)*	✓		
Air Remote TTL-N (For Nikon)**	✓		
Air Remote TTL-S (For Sony)***	✓		
Air Remote		✓	
Air Sync			✓

- * For the full list of tested Canon camera models, check latest release note for Air Remote TTL-C.
- $^{\star\star} \, \text{For the full list of tested Nikon camera models, check latest release note for Air Remote TTL-N}.$

Air Remote and Air Sync works with all cameras that have a hotshoe with ISO sync connection.



^{***} For the full list of tested Sony camera models, check latest release note for Air Remote TTL-S.